

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Elk Oil Company		8. Farm or Lease Name S. E. Anderson
3. Address of Operator Box 310, Roswell, New Mexico 88201		9. Well No. 1
4. Location of Well UNIT LETTER P , 660 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 19 TOWNSHIP 9S RANGE 35E NMPM.		10. Field and Pool, or Wildcat Undesignated
15. Elevation (Show whether DF, RT, GR, etc.) 4182 DF		12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

On Dec. 14, 1973 set 10 sx plug across Atoka perfs from 11477'-11484', Re-perforated from 9725'-9735' ISPF, 10 shots; 9843-9853' ISPF, 10 shots; Acid w/ (2) 500 gals stages and swabbed well for 5 days. Little water, no oil or gas.

Plan to Plug & Abandon as follows:

- (1) Place Western Co. Iron plug @ 9650' w/10' of cmt on top
- (2) Pull 5½" from approx. 5500'
- (3) Place cmt plugs @ 5500', 5½" casing stub; @ 4080' base of 9-5/8" casing
- (4) Pull 1000' 9-5/8" casing, place cmt plug @ 9-5/8" casing stub
- (5) Place cmt plug @ base of 13-3/8" casing @ 377' and 10 sx at surface
- (6) Place standard dry hole marker at surface.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE President DATE 12/27/73

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: