

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
102 and C-103
Effective 1-65
HUBBS OFFICE
Nov 23 11 30 AM '66

Incentive Type of Lease State <input type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. CG-854

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator Delaware-Apache Corporation 3. Address of Operator 1720 Wilco Building, Midland, Texas 4. Location of Well UNIT LETTER P 545 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 3 TOWNSHIP 10-South RANGE 33-East NMPM. 15. Elevation (Show whether DF, RT, GR, etc.)	7. Unit Agreement Name 8. Farm or Lease Name Sinclair-State 9. Well No. 1 10. Field and Pool, or Wildcat Middle Lane Penn. Ext. 12. County Lea
--	--

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Pump 25 sack cement plug across existing perforations from 9506'-9615'. Cut 5-1/2" production casing @ 8100' and pull same. Set cement plugs at the following intervals:

25 sacks in and out of 5-1/2" stub @ 8100'
25 sacks @ 6743'
25 sacks @ 5200'
25 sacks in and out of 8-5/8" intermediate casing @ 4000'

Cut 8-5/8" intermediate casing @ approximately 1500' and pull same, pump 25 sack cement plug in and out of 11-3/4" surface casing 35', mix 10 sacks and put in top of surface, weld plate and install dry hole marker.

Verbal permission granted to commence logging operations by Mr. Eric Engbrecht on November 22, 1966.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ray H. Bates TITLE Production Clerk DATE 11-22-66

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: