

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-7324

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input checked="" type="checkbox"/> GAS <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Western Equipment Company	8. Farm or Lease Name State
3. Address of Operator Box 5857 Midland, Texas 79701	9. Well No. 2
4. Location of Well UNIT LETTER 0 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 14 TOWNSHIP 10-S RANGE 33-E N.M.P.M.	10. Field and Pool or Wildcat Midland Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4198' gr.	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Commence work January 15, 1972

Set cast iron plug at 9685' above perforations (9692-9706' 20 .484" holes) and spot 2 sacks cement.

Shoot 5 1/2" casing at 4400' and spot 25 sacks plug in the stub then pull to the bottom of the 8-5/8" intermediate and spot 25 sack plug and pull remaining casing. Intermediate set to 4000'.
50

Shoot 8-5/8" at 1000', pull and set 25 sack plug at the surface and mark as an abandoned well.
(If more than 2000' of 8-5/8" is pulled a 25 sack plug will be set at the stub.)

If eq. recovered is below 4400' contact Hobbs OCC office
50 sacks in + out of 8 5/8" shoe
35 sacks @ 8 5/8" stub regardless of amount pulled
35 " in + out of 13 3/4" shoe, Heavy mud between plugs
24 hr. notice to Hobbs OCC office prior to setting plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>Eugene R. Murray</i>	TITLE Owner	DATE December 28, 1971
APPROVED BY <i>J. D. [Signature]</i>	TITLE SUPERVISOR DISTRICT I	DATE JAN - 5 1972
CONDITIONS OF APPROVAL, IF ANY:		