

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE ☒ FEE ☐
6. State Oil & Gas Lease No. OG 5338
7. Lease Name or Unit Agreement Name Harris State
8. Well No. 1
9. Pool name or Wildcat In the Permian

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER	
2. Name of Operator Bison Petroleum Corporation	
3. Address of Operator 5809 S. Western Suite 200 Amarillo Texas	
4. Well Location Unit Letter L : 2086 Feet From The South Line and 554 Feet From The West Line Section 5 Township 11-S Range 34 E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4212 RKB	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK ☐	REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐	ALTERING CASING ☐
PULL OR ALTER CASING ☐	COMMENCE DRILLING OPNS. ☐
OTHER: ☐	PLUG AND ABANDONMENT ☐
	CASING TEST AND CEMENT JOB ☐
	OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
1. Move in Rig up Plugging unit Pull Rods + Pump Pull 2 1/2" Tbg.
 2. Rig wireline unit Run CIBP To 9156' +/- Set Plug Dump 35' of Cement
 3. Run Tbg. Load hole with 10 # mud laden brine Pump 100' Plug at 6850' (25 SKS +/-)
 4. Pump 100' Plug at 3400 - 3300' (25 SKS +/-) Pull out with Tbg.
 5. Pick up on 5 1/2" CSQ. Shoot Pipe at free point Lay down CSQ.
 6. Run Tbg. To cut point 50' in 50' out Pump Cement Plug (40 SKS +/-) Tag with Tbg.
 7. Pump 100' Plug ~~4050~~ 3990 (45 SKS +/-) Tag with Tbg. Pull out of hole
 8. Perforate well at 1950' Run in Tbg. Pump 100' Plug (40 SKS +/-) Pull out Tbg.
 9. Pick up on 8 3/8" CSQ. Shoot Pipe at free point Lay down CSQ.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J. K. Rawlinson TITLE Agent DATE 29 Mar. 79
TYPE OR PRINT NAME TELEPHONE NO.

(This space for State Use)

Orig. Signed by
Paul Kautz
Geologist

MAR 29 1989

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

10. Run Tbg. To cut of $8\frac{3}{4}"$ Csg. (Pump 100' 50' in 50' out) (50 SKS +/-)
11. Pump 100' Plug. 400 - 300' (65 SKS +/-)
12. 10 SKS Surface Plug

Install dry hole marker (clean loc. Rig down

END 20 155

JCL

NOBBS 20 155