

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.
K 5442

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator MONSANTO COMPANY	8. Farm or Lease Name MGF "B" State
3. Address of Operator 101 North Marienfeld, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER I, 1980 FEET FROM THE South LINE AND 660 FEET FROM East THE LINE, SECTION 25 TOWNSHIP 10S RANGE 33E NMPM.	10. Field and Pool, or Wildcat Vada (Penn)
15. Elevation (Show whether DF, RT, GR, etc.) 4240' RKB	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This oil well is depleted; request is made to plug and abandon as follows:

- Set cast iron bridge plug at 9900' above perforations (9960-80') w/ 35' cement plug on top.
- Displace hole w/ 10.5# mud.
- Shoot off 5½" casing above top cement and pull. Set 100' cement plug in stub.
- Set 100' cement plug at base of 8 5/8" at 4010'.
- Shoot off 8 5/8" casing above top cement and pull. Set 100' cement plug in stub.
- Set 100' cement plug at base of 11 3/4" casing at 376'.
- Set 10 Sx plug in 11 3/4" casing at surface w/ 4" pipe marker at surface.

→ set 100' plugs across ^{top} Abo & Glorieta formations if not behind pipe.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. W. Wood TITLE District Production Manager DATE 4/18/72

APPROVED BY John Runyan TITLE Geologist DATE APR 20 1972

CONDITIONS OF APPROVAL, IF ANY: