

Submit 1 Copy To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
October 13, 2009

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-007-20290
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name VPR D
8. Well Number 046
9. OGRID Number 180514
10. Pool name or Wildcat

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other Coal Bed Methane	
2. Name of Operator El Paso E&P Company, L.P.	
3. Address of Operator 1001 Louisiana, Attn: Maria Gomez, Houston, TX 77002	
4. Well Location Unit Letter G : 1736.2 feet from the South line and 1737.9 feet from the East line Section 3 Township 30N Range 18E NMPM County Colfax	
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

This work is expected to begin approximately Thursday (05-19-11).

Set CIBP at 950' (top perf at 972'). Pressure test to 3000 psi. set 10 sack cement plug on the CIBP. Pull up hole set a 100' cement plug from 270' to 370'. The 8-5/8" casing shoe is at 320', but Ed likes to have this cement plug in the 5-1/2" casing across the area of the shoe. Pull up hole set a 10 sk surface cement plug. Cut casings off 6' below G.L., weld on dry hole marker with API # along with Sec, TS and range and date of plugging. Remove above ground piping, meter run, etc.

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Maria S. Gomez TITLE Sr. Regulatory Analyst DATE 05/19/2011

Type or print name Maria S. Gomez E-mail address: maria.gomez@elpaso.com PHONE: 713-420-5038
For State Use Only

APPROVED BY: Ed Martin TITLE DISTRICT SUPERVISOR DATE 5/23/2011
Conditions of Approval (if any):