

Reviewed w/ BLM 11/8/2000

S/TA WELL LIST

Bass Ek L

	Inactive		
WELL	Date	Current Wellbore Configuration	Plan of Action
Bass 3 Federal #1	Jul-95	Left rods & tbq in hole.	PxA
Bass 10 Federal #2	Sep-93	TA'd 9/12/97: LD rods & tbq, MIT - 750 psi.	Request TA extension. Plan to return to prod by re-installing FxB lift.
Big Eddy #10	Dec-89	TA'd 12/89: LD tbq, MIT - 500 psi. 5/98: MIT - 500 psi	Request TA approval. Plan to recomplete to Bone Spring.
Big Eddy #33	May-00	Left rods & tbq in hole.	Return to production. Re-design rod string.
Big Eddy #38	Apr-90	TA'd 6/94: Set CIBP, circ pkr fluid, MIT - 500 psi, left tbq in hole.	Recomplete to Bone Spring.
Big Eddy #40	Sep-78	TA'd 10/78; Left tbq, RTTS pkr & RBP in hole; MIT 6/98: 500 psi	Request TA extension. Possible directional well in Strawn.
Big Eddy #41	Dec-87	Left 2-7/8" tbq in hole; MIT 4/95: 550 psi	Request TA approval. Run MIT. Return to prod in LP system or recomplete to Bone Spring.
Big Eddy #44	Aug-98	Left tbq and pkr in hole	Request TA approval. Run MIT. Engr to review for frac stimulation.
Big Eddy #54	Jun-95	Left tbq and pkr in hole; Tstd csg to 1000 psi 5/95 during recompletion.	Request TA approval. Run MIT. Return to prod or recomplete to Wolfcamp
Big Eddy #60	Dec-82	Left tbq and pkr in hole	Not on Federal acreage. Run MIT for NMOCD.
Big Eddy #64	Sep-96	Left tbq in hole, LD rods and pump.	Return to prod within 60 days. Re-install FxB lift.
Big Eddy #66	Jan-97	Left tbq and pkr in hole; Tstd csg to 1000 psi 4/95 during recompletion	Request TA approval. Run MIT. Return to prod in LP gas system.
Big Eddy #70	Feb-90	Left tbq and pkr in hole; MIT 3/95: 590 psi.	Request TA approval. Run MIT. Return to prod or recomplete to Morrow and frac stimulate.
Big Eddy #71	Jan-85	TA'd 1/96; Left tbq in hole; MIT 1/96: 530 psi	Request TA approval. Run MIT. Recomplete to Delaware.
Big Eddy #73	Feb-98	Left tbq and pkr in hole	Return to prod within 60 days by installing FxB lift.
Big Eddy #80	Mar-88	Left tbq and pkr in hole; MIT 3/95: 580 psi	Request TA approval. Run MIT. Test Lower Morrow or recomplete to Bone Spring.
Big Eddy #83	Jan-85	Left tbq and pkr in hole; MIT 10/93: 590 psi	Request TA approval. Run MIT. Recomplete to Bone Spring or Delaware.
Big Eddy #84	Jun-92	Left tbq and pkr in hole.	Request TA approval. Run MIT. Hold for future SWD.
Big Eddy #92	May-97	Left tbq and pkr in hole.	Return to prod within 60 days by installing compression or tying into LP gas system.
	Inactive		

S/TA WELL LIST

WELL	Date	Current Wellbore Configuration	Plan of Action
Big Eddy #93	Aug-92	Left tbg and pkr in hole; Tstd csq to 2000 psi 7/92 during recompleiton.	Request TA approval. Run MIT. Return to prod in LP gas system.
Big Eddy #94	Nov-95	Left tbg and pkr in hole.	Return to prod by 1/17/00 by installing RxB lift.
Big Eddy #133	Jan-00	Left tbg and rods in hole.	Return to prod within 60 days.
Golden 8 Federal #4	Apr-95	TA'd 10/99; Left tbg in hole; MIT 10/99: 500 psi	Request TA extension. Run MIT. Convert to SWD.
Hopeful Federal #1	Mar-86	TA'd 7/98; Nothing in hole; MIT 3/95: 560 psi.	PxA. May have to drill out upper CIBP.
James Ranch #10	Jul-97	Tbg and pkr in hole	Return to prod within 60 days. Change out tbg or recomplete to Morrow.
Meridian State #4	Jan-97	PxA. Left change on wellhead for easy removal all necessary couplings in place	Not on Federal acreage
Poker Lake #41	Dec-99	TA'd 6/00; Left tbg in hole; MIT 6/00: 500 psi	Review old frac stimulation study by RMC.
Poker Lake #42	Jun-83	Workover in progress to recomplete in Morrow	Return to prod in Morrow or Wolfcamp.
Poker Lake #49	May-93	TA'd 5/95; Left tbg and pkr in hole; MIT 5/95: 540 psi	Request TA approval. Run MIT. Return to prod in one of various zones.
Poker Lake #52	Mar-95	Left tbg and pkr in hole; MIT 3/95: 540 psi	Request TA approval. Run MIT. Recomplete to Wolfcamp.
Poker Lake #57	Jun-95	TA'd 6/95; Nothing in hole; MIT 6/95: 530 psi.	Request TA approval. Run MIT. Recomplete to Bone Spring.
Poker Lake #58	Jan-95	TA'd 1/93; Left 1000' tbg in hole; MIT 3/95: 520 psi	Request TA approval. Run MIT. Possible sidetrack to Morrow.
Poker Lake #60	Oct-91	Rods and tbg in hole	PxA.
Poker Lake #91	Dec-99	Rods and tbg in hole	Request TA approval. Run MIT. Hold for SWD.
Poker Lake #98	Dec-97	Nothing in hole; Waiting on BLM approval for conversion to SWD.	WO BLM surface approval for conversion to SWD.
Rodke Federal #2	May-95	TA'd 5/95; Left rods and tbg in hole; MIT 5/95: 500 psi	Request TA extension. Run MIT. Possible sidetrack to Delaware. BLM has denied several Delaware APD's in this area due to potash. Cancel sundry requesting PxA approval.