STATE OF NEW MEXICO ENERGY AND MINERALS DEPARTMENT

80. 90 EBPIER ALCEIVER	
DISTRIBUTION	
BANTA PE	
FILE	 1
U.3.0.5.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION P. O. BOX 2088

Form C-103 . Revised 10-1-78

BANTA PE	SANTA FE, NEW MEXICO 87501	
FILE		5a, Indicate Type of Lease
U,3.0.3.		State Fee X
LAND OFFICE		5. State Oil 6 Gas Lesse No.
OPERATOR		
		mmmmmm -
SUNDRY NO	TICES AND REPORTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSAL	S TO ONLY LOW TO DEEPEN OF PLUG DACK TO A DIFFERENT RESERVOIR TREMET -" FORM C-1011 FOR SUCH PROPOSALS.)	
. 		7, Unit Agreement Name
01L GA8 GA8 GA8 GA8	THER- P&A	A. Farm or Lease Name
, Name of Operator	T-4 Filly's Tooth	
Yates Petroleum Corpora	ation	
Address of Operator		9. Weil No.
207 South 4th St. Arti	1	
207 South 4th St., Artesia, NM 88210		. 10. Field and Pool, c: wildcat
t. Location of Well	756.2	Undesignated
L 2265.	9 FEET FROM THE South LINE AND 756.2	LEGI LEON LILLIANIA
West	12 TOWNSHIP 10N RANGE 27E	имрм. (////////////////////////////////////
THE LINE, SECTION		
TID TITTETTE	15. Elevation (Show whether DF, RT, GR, etc.)	12. County
	4295.7' GR	Quay
	All Para	Other Data
	ropriate Box To Indicate Nature of Notice, Repo	ort or Other Data
NOTICE OF INTE	NTION TO: SUBS	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON X REMEDIAL WORK	ALTERING CASING
	COMMENCE DRILLING OPHS.	PLUG AND ABANDONMENT
TCMPORABILY ABANDON	CHANGE PLANS CASING TEST AND CEMENT JO	
PULL OR ALTER CASING	OTHER	
•		
OTHER		
	ions (Clearly state all pertinent details, and give pertinent dates	s, including estimated date of starting any proposed
17. Describe Proposed or Completed Operat work) SEE RULE 1103.	ions (Clearly State att personal account and	
TD 7705'		
	pandon well as follows:	
Propose to plug and at	on existing retainer @7240' with top of	plug up to 7040' or higher.
1. Spot cement plug of	Dans perforations 7003-7107! Tag	this plug.
This plug will cover o	open Penn perforations 7093-7197'. Tag	
		t hand log shows cement ton

- 2. Cut and pull 5½" casing from approximately 5350'. Cement bond log shows cement top at 5415'.
- Spot 100' cement plug 50' in and out of $5\frac{1}{2}$ " casing stub.
- Spot 100' cement plug from 3400-3500' across top of Abo/Sangre De Christo @3442'.

5. Spot 100' cement plug from 2680 2730'.)-2780 '	across 8-5/8" intermediate	casing shoe at		
6. Put 15 sack cement plug at surface with regulation abandonment marker.					
Note: All plugs except surface plug will consist of at least 35 sacks of cement.					
18. 1 Neveby certify that the information above is true and complete to the best of my knowledge and belief.					
minh anto Doublett		Production Supervisor	0ATE 6-26-85		
APPROVED BY	71768_	ASOR	DATE 7-2-85		
CONDITIONS OF APPROVAL, IF ANY:		·			