

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals, and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I

P.O. Box 1980, Hobbs, NM 88240

DISTRICT II

P.O. Drawer DD, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088

Santa Fe, New Mexico 87504-2088

WELL API NO.

30-059-20022

5. Indicate Type of Lease

STATE ☐

FEE ☐

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

BRAVO DOME CO2 GAS UNIT

1. Type of Well

OIL  
WELL ☐

GAS  
WELL ☐

OTHER CO2

2. Name of Operator

AMOCO PRODUCTION COMPANY

8. Well No.

2433-361G

3. Address of Operator

P.O. Box 303, AMISTAD, NEW MEXICO 88410

9. Pool name or Wildcat

BRAVO DOME CO2 GAS UNIT

4. Well Location

Unit Letter G : 1980 Feet From The North Line and 1980 Feet From The East Line  
Section 36 Township 24N Range 33E NMPM Union County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
5096 GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER ☐

12. Describe Proposed or Completed Operations

(Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work)

SEE RULE 1103.

MIRUSU, kill well as necessary, NUBOP, release packer, lay down production tubing and packer, run cast iron bridge plug with wireline, set CIBP at 2,474 feet, run workstring, displace casing with mud laden fluid, pressure test casing to 500 psi, cap CIBP with 3 sacks of cement, pull workstring to 2,030 feet, spot 10 sacks of cement, pull workstring to 30 feet, fill casing with cement, NDBOP, cut off wellhead, install PXA marker, RDMOSU, cut off well anchors and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Danny J. Holcomb TITLE Field Foreman DATE 8-18-99

TYPE OR PRINT NAME Danny J. Holcomb TELEPHONE NO. (505) 374-3010

(This space for State Use)  
APPROVED BY [Signature] TITLE DISTRICT SUPERVISOR DATE 8/23/99

CONDITIONS OF APPROVAL IF ANY: