

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals, and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I

P.O. Box 1980, Hobbs, NM 88240

DISTRICT II

P.O. Drawer DD, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**

P.O. Box 2088

Santa Fe, New Mexico 87504-2088

**WELL API NO.**

30-059-20035

**5. Indicate Type of Lease**

STATE ☐

FEE ☐

**6. State Oil & Gas Lease No.**

**7. Lease Name or Unit Agreement Name**

BRAVO DOME CO2 GAS UNIT

**8. Well No.**

2232-281J

**9. Pool name or Wildcat**

BRAVO DOME CO2 GAS UNIT

**SUNDRY NOTICES AND REPORTS ON WELLS**

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

**1. Type of Well**

OIL  
WELL ☐

GAS  
WELL ☐

OTHER

CO2

**2. Name of Operator**

AMOCO PRODUCTION COMPANY

**3. Address of Operator**

P.O. Box 303, AMISTAD, NEW MEXICO 88410

**4. Well Location**

Unit Letter J : 1980 Feet From The South Line and 1980 Feet From The East Line  
Section 28 Township 22N Range 32E NMPM Union County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
4949 GR

**11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data**

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

**12. Describe Proposed or Completed Operations**  
SEE RULE 1103.

(Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work)

MIRUSU, kill well as necessary, NUBOP, release packer, lay down production tubing and packer, run cast iron bridge plug with wireline, set CIBP at 2,216 feet, run workstring, displace casing with mud laden fluid, pressure test casing to 500 psi, cap CIBP with 3 sacks of cement, pull workstring to 1,845 feet, spot 7 sacks of cement, pull workstring to 30 feet, fill casing with cement, NDBOP, cut off wellhead, install PXA marker, RDMOSU, cut off well anchors and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief

SIGNATURE

*DJ Holcomb*

TITLE

Field Foreman

DATE

8-18-99

TYPE OR PRINT NAME

Danny J. Holcomb

TELEPHONE NO

(505) 374-3010

This space for State Use)

APPROVED BY

*Ry E Johnson*

TITLE

DISTRICT SUPERVISOR

DATE

8/23/99

CONDITIONS OF APPROVAL, IF ANY.