OPT	ropriate District	Sta	te of New M	[exico			Form	C- .
Office District I		Energy, Min	erals and Nat	ural Resources			May	27, 2
1625 N. French Dr., Hot	bs, NM 88240				WELL API 1	NO.		
District II		OIL CONS	SERVATION	N DIVISION		-34206		
1301 W. Grand Ave., Ar District III	tesia, NM 88210		South St. Fra		5. Indicate 7			
1000 Rio Brazos Rd., Az	ntec, NM 87410				STAT		FEE _]
District IV		Sai	nta Fe, NM 8	3/303	6. State Oil		e No.	
1220 S. St. Francis Dr., 5 87505	Santa Fe, NM					V-4990		
S	UNDRY NO	TICES AND REPOR	TS ON WELL	S	7. Lease Na	me or Unit	Agreement	Naı
		OSALS TO DRILL OR TO			MUI	DCAT ST (COM	
PROPOSALS.)	JIR. USE APPL	JCATION FOR PERMIT"	(FORM C-101) FC	RECEIVED				
1. Type of Well: (Dil Well 🔲	Gas Well 🛛 Ot	her		8. Well Nun	nber	l	
2. Name of Operat				DEC 5 2005	9. OGRID N	Jumber 01	5363	
		RCHISON OIL & GA	S, INC.	OCD AFTER	A			
3. Address of Open			D DI ANO T	OCD-MITTER	10. Pool nar	ne or Wildo	at	
	1100) MIRA VISTA BLV	D., PLANO, I	X. /5093-4698	EMPI	RE MORR	JW, SOUT	H
4. Well Location								
Unit Lette		_: <u>1300</u> feet from			810 feet	from the _	EAST	
Section	11	Township				County	EDDY	
		11. Elevation (Sh	iow whether Di	R, RKB, RT, GR, etc.)			
Dia Dia Dia Tan	- A N		4					
Pit or Below-grade Tanl								
Pit typel	Depth to Ground	lwaterDistance fr	om nearest fresh	water well Dista	ance from nearest	surface water		
Pit Liner Thickness:	mi	l Below-Grade Tank	: Volume	bbls; Cons	struction Material	l		
PERFORM REMED	OIAL WORK		_	REMEDIAL WOR		☐ ALTE	RING CASI	NG
	DIAL WORK [BANDON [K LLING OPNS.[☐ ALTE	RING CASI	NG
PERFORM REMED TEMPORARILY AS PULL OR ALTER O OTHER:	DIAL WORK [BANDON [BASING [☐ PLUG AND ABAI☐ CHANGE PLANS☐ MULTIPLE COM	B	REMEDIAL WOR COMMENCE DRI CASING/CEMENT	K LLING OPNS.[T JOB	☐ ALTEI ☐ PANE	RING CASI A	
PERFORM REMED TEMPORARILY AS PULL OR ALTER O OTHER: 13. Describe pro	DIAL WORK [BANDON [CASING [Diposed or com	PLUG AND ABAI CHANGE PLANS MULTIPLE COM	PL Clearly state all	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, an	K LLING OPNS.[T JOB d give pertinen	☐ ALTEI☐ P AND	RING CASI A uding estim	nate
PERFORM REMED TEMPORARILY AE PULL OR ALTER O OTHER: 13. Describe pro of starting a	DIAL WORK [BANDON [CASING [Diposed or control of the control of	☐ PLUG AND ABAI☐ CHANGE PLANS☐ MULTIPLE COM	PL Clearly state all	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, an	K LLING OPNS.[T JOB d give pertinen	☐ ALTEI☐ P AND	RING CASI A uding estim	nate
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe pro of starting a or recomple	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM npleted operations. (C	PL Clearly state all 103. For Multi	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, an ple Completions: A	K LLING OPNS.[T JOB d give pertinenttach wellbore of	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nate
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM npleted operations. (C work). SEE RULE 1:	PL Clearly state all 103. For Multi	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, an ple Completions: A	K LLING OPNS.[T JOB d give pertinenttach wellbore of	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nate
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows:	PL Clearly state all 103. For Multi	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: Additional depth of 1	K LLING OPNS.[T JOB d give pertinenttach wellbore of the control	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nate
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM mpleted operations. (C work). SEE RULE 1 base of 9-5/8" interme sing as follows: Float Shoe	PL Clearly state all 103. For Multi ediate @ 2208	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: Ar to a total depth of 1	K LLING OPNS. T JOB d give pertinent tach wellbore of tach wellbore of the tach wellbore of tach wellbore of the tach wellbore of tach well wellbore of tach well wellbore of tach well wellbore of tach well wellbore of tach well wellbore of tach wellbore of tach wellbore of tach wellbore of	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nate
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COMI npleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermediating as follows: Float Shoe 5-1/2" 17#/FT P-11	PL Clearly state all 103. For Multi ediate @ 2208	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: Ar to a total depth of 1 1 43	K LLING OPNS. T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nate
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COMI Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar	PL Clearly state all 103. For Multi ediate @ 2208	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: Ar to a total depth of 1 43 1	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nateomp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11	PL Clearly state all lo3. For Multi ediate @ 2208	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: And to a total depth of 1 1 43 1 757	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nateo
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermediates follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80	PL Clearly state all lo3. For Multi ediate @ 2208	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: Additional A	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nateomp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COMI Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermosing as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80 Stage Tool	PL □ Clearly state all 103. For Multi ediate @ 2208* 0 LT&C 0 LT&C 0 LT&C	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: And to a total depth of 1 1 43 1 757 2541	K LLING OPNS.[T JOB d give pertinent tach wellbore of the control of the contro	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nateomp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermediates follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80	PL □ Clearly state all 103. For Multi ediate @ 2208* 0 LT&C 0 LT&C 0 LT&C	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: Additional A	K LLING OPNS.[T JOB d give pertinent tach wellbore of the control of the contro	☐ ALTEI☐ P AND It dates, including ram of p	RING CASI A uding estimoroposed co	nate
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" p	DIAL WORK [BANDON [BANDON [BANDON [BANDON [BANDON [BANDON BOTH [BANDON BOTH [BANDON BOTH [BANDON BOTH BANDON BANDON BOTH BANDO	PLUG AND ABAI CHANGE PLANS MULTIPLE COM mpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114	Clearly state all lo3. For Multi ediate @ 2208 of LT&C	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: Ai to a total depth of 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2	K LLING OPNS.[T JOB d give pertinent tach wellbore of the control of the contro	D170 + .2%	ading estimoroposed co	nateomp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" g	DIAL WORK [BANDON [BANDON [BANDON [BANDON [BANDON [BANDON BOTH [BANDON BOTH [BANDON BOTH [BANDON BOTH BANDON BOTH	PLUG AND ABAI CHANGE PLANS MULTIPLE COM mpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermosing as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114 9 SXS to reserve pit,	Clearly state all lo3. For Multi ediate @ 2208 of LT&C	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3	K LLING OPNS.[T JOB d give pertinent tach wellbore of the control of the contro	D170 + .2%	ading estimoroposed co :30 HR 11/	nate omp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe pro of starting a or recomple Drilled 8-1/2 Ran 5-1/2" p	DIAL WORK [BANDON [BANDON [BANDON [BANDON [BANDON [BANDON [BANDON BOTTON [BANDON BOTTON BANDON BOTTON BANDON BOTTON BANDON BANDO	PLUG AND ABAI CHANGE PLANS MULTIPLE COMI Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermosing as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114 9 SXS to reserve pit, followed by 356 SXS	Clearly state all 103. For Multi ediate @ 2208 0 LT&C 0 LT&C LT&C LT&C 40 SXS Class " 2 nd Stage w/ 1 13.0 PPG Class	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: As to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 S"C" + 1.66 D44 + .	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% D65. But	ading estimoroposed co :30 HR 11/	nate omp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe pro of starting a or recomple Drilled 8-1/2 Ran 5-1/2" p	DIAL WORK [BANDON [BANDON [BANDON [BANDON [BANDON [BANDON [BANDON BOTTON [BANDON BOTTON BANDON BOTTON BANDON BOTTON BANDON BANDO	PLUG AND ABAI CHANGE PLANS MULTIPLE COM mpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermosing as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114 9 SXS to reserve pit,	Clearly state all 103. For Multi ediate @ 2208 0 LT&C 0 LT&C LT&C LT&C 40 SXS Class " 2 nd Stage w/ 1 13.0 PPG Class	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: As to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 S"C" + 1.66 D44 + .	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% D65. But	ading estimoroposed co :30 HR 11/	iate omp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" J Set casing (e Bump plug. + .3% D113 Circulated 1	DIAL WORK [BANDON [BANDON [BANDON [BANDON [BANDON [BANDON [BANDON BOTTON [BANDON BOTTON BANDON BOTTON BOTTO	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114 59 SXS to reserve pit, followed by 356 SXS Rig Down BOP & S	Clearly state all lo3. For Multi ediate @ 2208 of LT&C	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: And to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 5 "C" + 1.66 D44 + .1 1 off casing. Release	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% 6% D20 + 5% D65. But 11/23/05.	ading estimoroposed co :30 HR 11/ :5% D46 + .3% :5% D44 + .3mp plug, flo	inate omp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" p Set casing (e Bump plug. + .3% D113 Circulated 1	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114 69 SXS to reserve pit, Followed by 356 SXS Rig Down BOP & Seminabove is true and contains	Clearly state all lo3. For Multi ediate @ 2208 of LT&C	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: And to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 s"C" + 1.66 D44 + t off casing. Release	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% 6% D20 + 5% D65. But 11/23/05.	ading estimoroposed composed c	aateeomp (19// % D 3% oats
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" p Set casing (e Bump plug. + .3% D113 Circulated 1	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114 59 SXS to reserve pit, followed by 356 SXS Rig Down BOP & S	Clearly state all lo3. For Multi ediate @ 2208 of LT&C	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: And to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 s"C" + 1.66 D44 + t off casing. Release	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% 6% D20 + 5% D65. But 11/23/05.	ading estimoroposed composed c	ate omp (19/
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" g Set casing (6 Bump plug. + .3% D113 Circulated 1 hereby certify that to trade tank has been/will	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114 69 SXS to reserve pit, Followed by 356 SXS Rig Down BOP & Seminabove is true and contains	Clearly state all 103. For Multi ediate @ 2208 0 LT&C 0 LT&C 0 LT&C 13.0 PPG Class et slips and curomplete to the OCD guidelines \(\frac{1}{2}\)	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: And to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 S"C" + 1.66 D44 + t off casing. Release best of my knowledg , a general permit of	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% 6% D20 + 5% D65. But 1/23/05.	ading estimoroposed composed composed composed composed composed composed composed composed place of the compo	inated omp
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" p Set casing (e Bump plug. + .3% D113 Circulated 1	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermeding as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT P-11 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 ement 1st Stage w/ 114 69 SXS to reserve pit, Followed by 356 SXS Rig Down BOP & Seminabove is true and contains	Clearly state all lo3. For Multi ediate @ 2208 of LT&C	REMEDIAL WOR COMMENCE DRI CASING/CEMEN OTHER: pertinent details, and ple Completions: And to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 s"C" + 1.66 D44 + t off casing. Release	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% 6% D20 + 5% D65. But 1/23/05.	ading estimoroposed composed c	inates omposition (19/0)
PERFORM REMED TEMPORARILY AB PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" g Set casing (6 Bump plug. + .3% D113 Circulated 1 hereby certify that to grade tank has been/will.	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermosing as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 Ement 1st Stage w/ 114 19 SXS to reserve pit, Followed by 356 SXS Rig Down BOP & S On above is true and conclused according to NM CULLING CHANGE PLANS AND HOLD TO SEE THE TO SEE TO	Clearly state all 103. For Multi ediate @ 2208* 0 LT&C 0 LT&C 1 LT&C 1 LT&C 2 LT&C 1 SXS Class " 2 PG Class et slips and cur complete to the OCD guidelines © TITLE	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: Aid to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 S"C" + 1.66 D44 + t off casing. Release best of my knowledged, a general permit of the completion of the com	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% 6% D20 + 5% D65. But 1/23/05.	ading estimoroposed composed c	inated omp.
PERFORM REMED TEMPORARILY AE PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" p Set casing (6 Bump plug. + .3% D113 Circulated 1 Thereby certify that to the control of the	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermosing as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 Ement 1st Stage w/ 114 19 SXS to reserve pit, Followed by 356 SXS Rig Down BOP & S On above is true and conclused according to NM CULLING CHANGE PLANS AND HOLD TO SEE THE TO SEE TO	Clearly state all 103. For Multi ediate @ 2208* 0 LT&C 0 LT&C 1 LT&C 1 LT&C 2 LT&C 1 SXS Class " 2 PG Class et slips and cur complete to the OCD guidelines © TITLE	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: And to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 S"C" + 1.66 D44 + t off casing. Release best of my knowledg , a general permit of	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% 6% D20 + 5% D65. But 1/23/05.	ading estimoroposed co :30 HR 11/ :30 HR 11/ :30 HR 11/ :30 HR 11/ :30 HR 11/ :40 D46 + .3% :30 HR 11/ :40 D46 + .3% :40 HR 11/ :40 PH 11/	ate omp (19/
PERFORM REMED TEMPORARILY AE PULL OR ALTER OF OTHER: 13. Describe proof starting a or recomple Drilled 8-1/2 Ran 5-1/2" p Set casing (6 Bump plug. + .3% D113 Circulated 1 hereby certify that to rade tank has been/will.	DIAL WORK [BANDON [BAN	PLUG AND ABAI CHANGE PLANS MULTIPLE COM Inpleted operations. (Cowork). SEE RULE 1: base of 9-5/8" intermosing as follows: Float Shoe 5-1/2" 17#/FT P-11 Float Collar 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 Stage Tool 5-1/2" 17#/FT N-80 Ement 1st Stage w/ 114 19 SXS to reserve pit, Followed by 356 SXS Rig Down BOP & S On above is true and conclused according to NM CULLING CHANGE PLANS AND HOLD TO SEE THE TO SEE TO	Clearly state all 103. For Multi ediate @ 2208* 0 LT&C 0 LT&C 1 LT&C 1 LT&C 2 LT&C 1 SXS Class " 2 PG Class et slips and cur complete to the OCD guidelines © TITLE	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: Aid to a total depth of 1 1 43 1 757 2541 2 7085 TOTAL 10430 C" + .3% D167 + .2 170 SXS 12.7 PPG 3 S"C" + 1.66 D44 + t off casing. Release best of my knowledged, a general permit of the completion of the com	K LLING OPNS.[T JOB d give pertinent tach wellbore of tach well wellbore of tach wellbore	D170 + .2% 6% D20 + 5% D65. But 1/23/05.	ading estimoroposed composed c	ateomp (19/ % D 3% or b or b 200 31-