

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

OIL CONSERVATION DIVISION
P. O. BOX 1088
SANTA FE, NEW MEXICO 87501
RECEIVED BY
MAR 25 1985
O. C. D.
ARTESIA, OFFICE

Form C-103
Revised 10-1-78

BLM

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry	7. Unit Agreement Name
2. Name of Operator Petrus Operating Company, Inc. ✓	8. Farm or Lease Name Moon Company 4
3. Address of Operator 12201 Merit Drive, Suite 900 Dallas, Texas 75251	9. Well No. 1
4. Location of Well UNIT LETTER J 1980 FEET FROM THE South LINE AND 1980 FEET FROM East THE LINE, SECTION 4 TOWNSHIP 9S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Wildcat - S.A.
15. Elevation (Show whether DF, RT, CR, etc.) 3969' GL	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

To plug and abandon the above well we propose to:

- Cement squeeze the perms from 2500-2538' with 50 sx of cement leaving the top of cement at or above 2400'. TOC will be tagged. *or CIBP W/35'CMT, **
* Load hole w/mud
- Spot a 100' cement plug across the top of the San Andres (1888' ELM) from 1840-1940' with 10 sx of cement. TOC will be tagged.
- Cut and pull the 4-1/2" casing at ±1400'.
- Spot a 250' cement plug across the stub and top of the Queen (1460' ELM) from 1300-1550' with 60 sx of cement. TOC will be tagged.
- Spot a 100' cement plug across the 8-5/8" shoe from 460-560' with 40 sx of cement. TOC will be tagged.
- Spot a 15 sx surface plug.
- Cut the 8-5/8" casing off 4' below ground level and install a 4" OD permanent marker.

Notary Public in sufficient time to witness

Plugging

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

marker.

SIGNED C. L. Hardy TITLE Drilling & Production Mgr. DATE 03-18-85

PROVED BY [Signature] TITLE OIL AND GAS INSPECTOR DATE APR 4 1985

CONDITIONS OF APPROVAL, IF ANY: * As Noted Above

PETRUS OPERATING COMPANY, INC.
 MOON COMPANY "4" NO. 1
 CHAVES COUNTY, NEW MEXICO
 1980' FSL & 1980' FEL OF S-4, TWP-9S, R-28E

PROPOSED P&A

