

RECEIVED

Form C-103
Revised 10-1-79

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

APR 01 '88

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.
LG 4920

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

O. C. D.
ARTESIA OFFICE

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Yates Petroleum Corporation ✓ 3. Address of Operator 105 South 4th St., Artesia, NM 88210 4. Location of Well UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 25 TOWNSHIP 9S RANGE 26E NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 3805.7' GR	7. Unit Agreement Name 8. Farm or Lease Name Ibis XU State Com 9. Well No. 2 10. Field and Pool, or Wildcat Undes. Wolfcamp 12. County Chaves
---	---

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER Propose to perforate, trt, Wolfcamp <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to set blanking plug in existing packer at 5792'. Load tubing and casing. Come off on/off tool and POOH w/tubing. Perforate Wolfcamp 5151-56' w/1 SPF (6 holes); 5240-46' w/2 SPF (12 holes). Spot acid on perfs 5240-46' and treat w/1000 gals 15% NEFE. Recover load and test. Kill zone 5240-46', set RBP approx. 5210' and pressure test. Spot acid on perfs 5151-56' and treat w/1000 gals 15% NEFE + balls. Recover load and test. TOOH w/tubing, packer and RBP. RIH w/tubing, blast joints across Wolfcamp perfs, sliding sleeve (open) at 5300', on/off tool. Set on/off tool back on packer at 5792'. Swab in Wolfcamp zones through sliding sleeve. Close sliding sleeve, load tubing and pull blanking plug from packer at 5792'. Swab in Penn zones. Propose to produce Wolfcamp zones up casing and Penn zones up tubing.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mike Williams TITLE Production Supervisor DATE 3-30-88

APPROVED BY Mike Williams TITLE Oil & Gas Inspector DATE MAY 16 1988

CONDITIONS OF APPROVAL, IF ANY: