

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

BLM Form 5100-5 (Rev. 11/97)
Bureau No. 1004-0135
Expires: March 31, 1999
5. Lease Designation and Serial No.

C/SF

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☐ Oil Well ☐ Gas Well ☒ Other INJECTION

2. Name of Operator
TIPTON OIL & GAS ACQUISITIONS

2. Address
P.O. BOX 1234, LOVINGTON, NM 88260

Telephone No.
505-631-1121

3. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Lot 1, Sec. 6, T15S, R30E

6. If Indian, Allottee or Tribe Name

7. If Not an FTA, Acquisition Designation

8910160560

8. Well Name and No.

Double L Queen Unit #003L

9. API Well No.

30-005-20346

10. Field and Pool, or Extension or Area
Double L Queen Associated

11. County or Parish, State

Chaves, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log Data.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measure (and true vertical depth) of all markers and zones pertinent to this work.)

Intend to P&A this SI WIW, we will notify OCD and BLM 24hrs prior to start
MIRU, POOH w/tbg (4-1/2" csg @ 2030' w/200 sx, with Perfs @ 1978 - 1989
Set CIBP @ 1928' w/ 35' cement on top
RIH, circ well w/9.8 mud *Perf. csg @ 1300' squeeze 100' of cmt inside: outside csg. 1200-1300 - T₉₉*
POOH to 1300', spot 100' cmt plug *Perf. csg. @ 408' - squeeze 100' of cmt inside: outside csg 308-408 - T₉₉*
POOH to ~~408~~ ⁴⁰⁸, spot 100' cmt plug (8 5/8" @ 406 w/300 sx), WOC & tag
POOH to ~~30~~ ⁶⁰, circulate cmt to surface *Perf. csg. @ 60' - circ cmt. 0-60'*
Cut of WH, install dry hole marker

14. I hereby certify that the foregoing is true and correct

Signed *[Signature]* Title Agent

Date 2-19-02

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any

[Signature]

Field Rep ID

MAR 5 2002