

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 87240  
District II  
811 South First, Artesia, NM 87210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION

2040 South Pacheco  
Santa Fe, NM 87505

WELL API NO.  
30-005-60154

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
K67721

7. Lease Name or Unit Agreement Name  
Double L Queen Unit Tract 21  
Agreement No 8910160560

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM CS-901) FOR SUCH  
PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☐ Other WIW

2. Name of Operator  
Saga Petroleum LLC /

3. Address of Operator  
415 W Wall, Suite 1900  
Midland, TX 79701

8. Well No. 1

9. Pool name or Wildcat  
Double L Queen

4. Well Location

Unit Letter M : 660 feet from the SOUTH line and 660 feet from the WEST line

Section 24 Township 14S Range 29E NMPM County CHAVES

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

3794 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOBS ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work). SEE RULE 1103. For Multiple Completions: Attach diagram of proposed completion or recompletion.

Intent to P&A this SI WIW, will notify OCD 24 hrs prior to start operations

MIRU. POOH w/rods, NU BOP, POOH w/tbg

Set CIBP @ 1930' w/35' cmt on top set CIBP @ 1833' w/35' cement to top CIBP.

RIH, circ well w/9.8# mud

POOH to 1300', spot 100' cmt plug Perforate 5 1/2" csg @ 1300'. Squeeze 100' cement Plug Inside + Outside 5 1/2" csg. TAG

POOH to 127', spot 100' cmt plug (8-5/8" @ 327'), WOC & tag Perforate 5 1/2" csg @ 377'. Squeeze 100' cement Plug

POOH to 30', circ cmt to surface

Cut off WH, install dry hole marker

Perforate 5 1/2" csg @ 50'.

Circulate cement to surface.

Inside + Outside 5 1/2" csg.

+ Brine gel between cement plugs.

Notify N.M.O.C.D. to witness plugging operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Bonnie Husband TITLE Production Analyst DATE 01/11/2001

Type or print name Bonnie Husband Telephone No. (915)684-4293

(This space for State use)

APPROVED BY Mina Swellfield TITLE Field Rep. II DATE 1/23/2001

Conditions of approval, if any: