

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Dry Hole	5. LEASE DESIGNATION AND SERIAL NO. NM-068043
2. NAME OF OPERATOR Read & Stevens, Inc. ✓	6. IF INDIAN, ALLOTTEE OR TRIBE NAME -
3. ADDRESS OF OPERATOR P.O. Box 2126, Roswell, New Mexico 88201	7. UNIT AGREEMENT NAME -
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FEL & 660' FSL Sec. 27, T-15-S, R-27-E, N.M.P.M.	8. FARM OR LEASE NAME Harris Federal
14. PERMIT NO.	9. WELL NO. 3
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3472.2' GR - 3484' RKB	10. FIELD AND POOL, OR WILDCAT Wildcat
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 27, T-15-S, R-27-E
	12. COUNTY OR PARISH Chaves
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

PBTD 1642' with perfs. 1434-54' (Premier sand) Propose to plug and abandon as follows:

1. Set cast iron bridge plug @ approximately 1150' above perfs. 1434-44' and spot 35' cement plug on top of bridge plug.
2. Cut and pull 8 5/8" casing @ approximately 950'.
3. Circulate hole full of good mud.
4. Set 100' cement plug 1/2 in and 1/2 out of 8 5/8" casing stub.
5. Set 100' cement plug 1/2 in and 1/2 out of 13 3/8" casing shoe @ 349' RKB.
6. Set 20' cement plug 20' to surface.
7. Install regulation marker.
8. Plugging operation to commence approximately 10/20/76.

RECEIVED

OCT 08 1976

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

Agent

DATE

10/6/76

TITLE

DATE