

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

NM Oil Cons. Commissi  
Drawer DD  
Artesia, NM 88210

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

MAY 14 1992

O. C. D.

OFFICE

1. Type of Well  
☐ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Siete Oil and Gas Corporation

3. Address and Telephone No.

P.O. Box 2523, Roswell, NM 88202-2523

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Sec. 15, T15S, R27E

990' FSL & 990' FEL

SE $\frac{1}{4}$ SE $\frac{1}{4}$ , Unit Letter P

5. Lease Designation and Serial No.

NM-0115465-A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Mojave Federal #1

9. API Well No.

30-005-62846

10. Field and Pool, or Exploratory Area

Buffalo Valley Penn

11. County or Parish, State

Chaves NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

RU pulling unit, kill well w/kill truck, break out surface equip., release pkr, TOH w/tbg, PU 5 $\frac{1}{2}$ " CIBP, TIH to 8175' & set CIBP, turn hole over w/9.5# brine water w/25# salt water gel per bbl, spot 10 sxs CC Neet on top of CIBP, pull tbg to 6405', set plug w/25 sxs CC, TOH w/tbg, RU Black Warrior, TIH w/wireline, free point csg, TOH, PU 5 $\frac{1}{2}$ " chemical cutter, TIH & cut csg 50' above free point @ approx. 1850', TOH & lay dn csg, TIH w/tbg open-ended to depth of 50' below stub & set 25 sxs plug, tag plug, pull tbg to 1670' & set plug w/40 sxs CC, 4% CaCl, wait 2 hrs, tag plug, if plug if 1560' or above pull to 415', if not set second plug to reach height of at least 1560', then pull to 415' & set 35 sxs plug, pull tbg to 60', fill 8 5/8" csg to surface w/CC Neet, erect dry hole marker.

A verbal on the above procedure was given by Pete Chester on 4/29/92.

14. I hereby certify that the foregoing is true and correct

Signed Cathy Bailey-Seely

Title Drilling Technician

Date 5/1/92

(This space for Federal or State office use)

Approved by \_\_\_\_\_  
Conditions of approval, if any:

Title \_\_\_\_\_

APPROVED  
PETER W. CHESTER  
Date

MAY 11 1992

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side

BUREAU OF LAND MANAGEMENT  
ROSWELL RESOURCE AREA