

UNITED STATES GEOLOGICAL SURVEY
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate
(Other instruction
verse side)Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

LC-061638

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Water Injection	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR General American Oil Company of Texas ✓	8. FARM OR LEASE NAME Brewer
3. ADDRESS OF OPERATOR P. O. Box 128 Loco Hills, New Mexico 88255	9. WELL NO. # 12
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FSL and 659' FWL	10. FIELD AND POOL, OR WILDCAT High Lonesome
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 13, T-16S, R-29E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3727' DF	12. COUNTY OR PARISH Eddy
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input checked="" type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well as follows:

1. Pull tubing.
2. Run casing scraper.
3. Run freepoint and shoot 7" casing off and pull from hole.
4. Run in hole with tubing and spot 100' cement plug, 2134'-2034'.
(This will cover open hole section 2105'-2134').
5. Set 100' cement plug where casing was shot off. (50' in and 50' out of casing stub).
6. Set 100' cement plug from 965'-865'. (Base of Salt 915').
7. Set 100' cement plug from 545'-445'. (Top of Salt 495').
8. Set 100' cement plug from 300'-400'. (Across water zone).
9. Set 10 sack cement plug at surface and install dry hole marker.
10. Remove all debris from location and fill pits. Rip location and roads as necessary.

18. I hereby certify that the foregoing is true and correct

SIGNED

Rendell H. Hawkins

TITLE

Field Superintendent

DATE

February 5, 1981

(This space for Federal or State office use)

APPROVED BY

(Orig. Sgd.) PETER W. CHESTER

TITLE

ACTING DISTRICT ENGINEER

DATE

FEB 10 1981

CONDITIONS OF APPROVAL, IF ANY: