

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

LC-067610-a

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Bosworth

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

High Lonesome

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 14, T-16S, R-29E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection

2. NAME OF OPERATOR

General American Oil Company of Texas ✓

3. ADDRESS OF OPERATOR

P. O. Box 128 Loco Hills, New Mexico 88255

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

1980' FSL and 1980' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3726' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well as follows:

1. Pull tubing.
2. Run casing scraper.
3. Run freepoint and shoot 5-1/2" casing off and pull from hole.
4. Run in hole with tubing and spot 100' cement plug, 2070'-1970'.
(This will cover open hole section 2041'-2070').
5. Set 100' cement plug where casing was shot off. (50' in and 50' out of casing stub).
6. Set 100' cement plug from 915'-815'. (Base of Salt 865').
7. Set 100' cement plug from 510'-410'. (Top of Salt 460').
8. Set 100' cement plug from 300'-400'. (Across water zone).
9. Set 10 sack cement plug at surface and install dry hole marker.
10. Remove all debris from location and fill pits. Rip location and roads as necessary.

18. I hereby certify that the foregoing is true and correct.

SIGNED Rendell N. Hawkins

TITLE Field Superintendent

DATE February 5, 1981

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER TITLE ASSISTANT DISTRICT ENGINEER

CONDITIONS OF APPROVAL, IF ANY:

DATE FEB 10 1981