

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐ Plug & Abandon
2. NAME OF OPERATOR McClellan Oil Corporation 505-622-3200
3. ADDRESS OF OPERATOR P.O. Drawer 730 Roswell, NM 88202-0730
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface Unit G 2310 FNL & 1980 FEL

RECEIVED

AUG 19 1991

O. C. D.
ARTESIA, OFFICE

5. LEASE DESIGNATION AND SERIAL NO.
NM-0916
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Simmons Federal
9. WELL NO.
#1
10. FIELD AND POOL, OR WILDCAT
W. Henshaw Grayburg
11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
Sec 24-T16S-R29E
12. COUNTY OR PARISH
Eddy
13. STATE
NM

14. PERMIT NO.
15. ELEVATIONS (Show whether DF, RT, GR, etc.)
3729' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) P & A

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)

4½ csg 2675' Perfs 2660'-2670'
2 3/8 tbg Salt Top 480'
TOC 2150 Bottom 963'

- Set CIBP at 2600' & put 35' cmt on top.
- Shoot csg qff at 2100' & pull out of hole.
- 1st plug 2150' to 2050' 35 sx Tag
2nd plug 1013' to 913' 30 sx
3rd plug 530' to 430' 30 sx Tag sjs
4th plug 60' to Surface 20 sx

Clean location & install dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

Mark Lee

TITLE Drlg. & Comp. Engineer

DATE 5-23-91

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

Mark Lee

DATE 8/15/91

*See Instructions on Reverse Side