

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPL
(Other instructions
reverse side)

E*

copy to SF
Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO. NM-12764
2. NAME OF OPERATOR General American Oil Company of Texas	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P. O. Box 416 Loco Hills, New Mexico 88255	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2310' FNL and 330' FEL	8. FARM OR LEASE NAME Nunlee
14. PERMIT NO.	9. WELL NO. 5
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3678' DF	10. FIELD AND POOL, OR WILDCAT Square Lake
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 35, T-16S, R-29E
	12. COUNTY OR PARISH Eddy
	13. STATE New Mexico

MAR 9 1977

O. G. G.
ARTESIA, OFFICE

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	<input type="checkbox"/>	PULL OR ALTER CASING	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	MULTIPLE COMPLETE	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	ABANDON*	<input checked="" type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	CHANGE PLANS	<input type="checkbox"/>
(Other)			

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
FRACTURE TREATMENT	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
SHOOTING OR ACIDIZING	<input type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
(Other)			

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work).*

WE PROPOSE TO PLUG AND ABANDON THIS WELL BY:

1. Rig up and run freepoint, shoot 5-1/2" casing off (approximately 1700') and pull from hole.
2. Go in hole with tubing and spot 150' cement plug from 2500' back to 2350'. (Cast iron bridge plug set at 2500' also this will cover existing perforations from 2455'-2465'.)
3. Set 100' cement plug (50' inside and 50' outside casing stub) where ever casing is shot off.
4. Set 100' cement plug from 1040'-940'. (Base of salt at 990').
5. Set 100' cement plug from 550'-450'. (8-5/8" casing set at 497').
6. Set 20' cement plug at surface and install dry hole marker.
7. Remove all debris from location and fill pits. Rip location and roads as necessary.

RECEIVED

FEB 28 1977

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED Lendee HawkinsTITLE District EngineerDATE February 25, 1977

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side