

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Budget Bureau No. 1004-C-11

Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM 0560379

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection

2. NAME OF OPERATOR

Kay Jay Oil Co.

3. ADDRESS OF OPERATOR

P.O. Box 3565 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with all State requirements.
See also space 17 below.)

At surface 660' FNL-660' FWL-Sec.17-T16S-R30E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3774' GL

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Propose to P & A subject waterflood injection well due to termination of water injection as follows:

1. Set CIBP @ 2600' w/15 sx. cement on top of plug.
2. Spot 25 sx. cement plug 2050'-1800'. (Top of Queens)
3. Pressure test casing.
4. Perforate @ 1200' & spot 35 sx. cement plug. (100' inside & 100' outside) WOC & tag plug.
5. Perforate @ 575' & spot 35 sx. cement plug (100' inside & 100' outside) WOC & tag plug.
6. Set 10 sx. surface plug.
7. Install dry hole marker & restore location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side