

RECEIVED BY

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN T

(Other Instruct

verse side)

DATE

Form approved.

Budget Bureau No. 1004-0110

Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM 0610

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

SW Henshaw Premier Unit

8. FARM OR LEASE NAME

9. WELL NO.

12

10. FIELD AND POOL OR WILDCAT

West Henshaw Grayburg

11. SEC., T., R., M., OR BLM. AND
SURVEY OR AREA

Section 18-T16S-R30E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

NOV 4 1985

O. C. D.

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. ARTESIA, OFFICE

WELL ☐ WELL ☐ OTHER ☐

Water Injection

2. NAME OF OPERATOR

Kay Jay Oil Co. ✓

3. ADDRESS OF OPERATOR

P.O. Box 3565 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

660' FSL-1980' FWL-Sec.18-T16S-R30E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3754' GL

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*Propose to P & A subject waterflood injection well due to termination of
water injection as follows:

1. Set CIBP @ 2600' w/ 15 sx. cement of top of plug.
2. Spot 25 sx. cement plug 2050'-1800' (Top of Queens)
3. Pressure test casing to determine any additional repair plugs.
4. Perforate @ 1200' & spot 35 sx. cement plug. (100' inside & 100' outside) WOC & tag plug
5. Perforate @ 450' & spot 35 sx. cement plug (100' inside & 100' outside) WOC & tag plug
6. Set 10 sx. surface plug.
7. Install dry hole marker & restore location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Agent

DATE

7/19/85

(This space for Federal or State Office use)

APPROVED BY

TITLE

DATE

11-1-85

CONDITIONS OF APPROVAL, IF ANY:

Subject to
Like Approval

*See Instructions on Reverse Side

Under the provisions of the Federal False Claims Act, 18 U.S.C. § 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.