

RECEIVED BY
JAN 25 1985
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different ARTESIAN OFFICE-331-C for such proposals.)

1. oil ☐ gas ☐ other ☒ water injection
2. NAME OF OPERATOR
Kay Jay Oil Co.
3. ADDRESS OF OPERATOR
P.O. Box 3565 Midland, Texas 79702
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1980'FSL-1980'FEL-Sec. 18-T16S
AT TOP PROD. INTERVAL: R30E
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)		

5. LEASE
NM 0610
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
Southwest Henshaw Premier Unit
8. FARM OR LEASE NAME
9. WELL NO.
10
10. FIELD OR WILDCAT NAME
West Henshaw Grayburg
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 18 - T16S - R30E
12. COUNTY OR PARISH
Eddy
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
3758' DF

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to P & A subject waterflood injection well due to termination of water injection as follows:

1. Set CIBP @ 2676' w/35' cement on top.
2. Spot 25 sx. cement plug 1990'-1890' (top of queens)
3. Pressure test casing
4. Perforate & spot cement plug (45 sx. w/100'inside & 100' outside)
5. Perforate & spot 45 sx. cement plug @ 1045'. (100' inside & 100' outside) WOC & tag plug
6. Perforate & spot 45 sx. cement plug @ 500'. (100' inside & 100' outside) WOC & tag plug.
7. Spot 10 sx. repair plug @ 300'. WOC & tag plug.
8. Set 10 sx. surface plug.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED T. D. Biff TITLE Agent DATE 8/15/84

(This space for Federal or State office use)
APPROVED BY San Wood Acting AREA MANAGER
CONDITIONS OF APPROVAL, IF ANY 09 TITLE CARLSBAD RESOURCE AREA DATE 1-26-85

Subject to
Like Approval
by State

*See Instructions on Reverse Side

