

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

16 063103

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Sheldon Fed.

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Square Lake

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 28, T-16S, R-31E NMPM

12. COUNTY OR PARISH

Socorro

13. STATE

N.M.

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Kennedy Oil Co., Inc. ✓

AUG 14 1974

3. ADDRESS OF OPERATOR

Box 151 Artesia, New Mexico 88210

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface2310' FSL (NE 1/4 SE 1/4)
660' FSL Sec. 28, T-16S, R-31E NMPM

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4033 GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

Plug and abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug and abandon as follows:

1. Place a C.I. bridge plug @ 3400' and cap with a 35' cement plug.
Tops: Queen 2845, B.S. 1840', TS 770'.
2. Place a C.I. bridge plug at 3065' and cap with a 35' cement plug above perforations 3069-3130'.
3. Place a 100' cement plug at pipe stub.
4. If pipe stub exceeds 800' below base of salt place a 100' cement plug @ base of salt 1890'-1790'.
5. Place a 100' cement plug at surface csg. shoe 785-685'.
6. Place a 20' cement plug at surface csg. 20'-0'.
7. Place heavy mud between all plugs.
8. Set regulation marker, clear, clean, and level location & notify for inspection.
9. The above work will commence August 7-8, 1974.

RECEIVED

AUG -6 1974

U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Pres.

DATE

8/5/74

(This space for Federal or State office use)

TITLE

DATE

APPROVED

CONDITIONS OF APPROVAL, IF ANY:

AUG 13 1974

R. L. BEEKMAN

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.



OIL CONSERVATION COMMISSION

STATE OF NEW MEXICO
P. O. DRAWER DD - ARTESIA
88210

I. R. TRUJILLO
CHAIRMAN
LAND COMMISSIONER
ALEX J. ARMIJO
MEMBER
STATE GEOLOGIST
A. L. PORTER, JR.
SECRETARY - DIRECTOR

August 3, 1973

Kennedy Oil Company, Inc.
P. O. Box 151
Artesia, New Mexico

Re: Shut-in wells

Gentlemen:

We note from recent production reports that the subject wells have not been producing. Therefore, unless notified otherwise by Form C-127, the wells involved will receive no allowable beginning September 1, 1973.

Grayburg Jackson
New Mexico "BG" State #1-I, 2-17-31

Square Lake
Kennedy Federal #4-A, 28-16-31
Sheldon Federal #5-I, ✓

Sincerely yours,

OIL CONSERVATION COMMISSION

W. A. Gressett
Supervisor, District II

WAG:jw