

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

**RECEIVED**  
NEW MEXICO OIL CONSERVATION COMMISSION

**AUG 28 1974**

**O. C. C.**

**ARTESIA OFFICE**

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

**SUNDRY NOTICES AND REPORTS ON WELLS**

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator <b>Kennedy Oil Co., Inc.</b>		5. State Oil & Gas Lease No. <b>B-2721</b>
3. Address of Operator <b>Box 151 Artesia, New Mexico 88210</b>		7. Unit Agreement Name
4. Location of Well UNIT LETTER <b>H</b> <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>East</b> LINE, SECTION <b>32</b> TOWNSHIP <b>16S</b> RANGE <b>31E</b> NMPM.		8. Farm or Lease Name <b>State "C"</b>
		9. Well No. <b>3</b>
		10. Field and Pool, or Wildcat <b>Square Lake</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3944 DF</b>		12. County <b>Eddy</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Propose to plug and abandon as follows:**

**Set C.I. bridge plug @ 3150' and cap with 30' cement plug.  
Place heavy mud between plugs.  
Pull recoverable 5½" csg. above cement top estimated @ 2450'  
Place 100' cement plug @ pipe stub if stub is over 800' below base of salt.  
Place 100' cement plug @ base of salt 1565-1665'.  
Place 100' cement plug @ top of salt 595-695'.  
Pull recoverable 8 5/8" csg. and place a 35 sack cement plug in stub.  
Place surface plug, clean clear and level location and place regulation marker.  
Will advise commission when plugging will commence.**

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *L.B. Kennedy*

TITLE **President**

DATE **8/28/74**

APPROVED BY *W.A. Gressett*

TITLE **OIL AND GAS INSPECTOR**

DATE **AUG 29 1974**

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

*Plugging*