

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

RECEIVED
Santa Fe, New Mexico 87501-2088

JUN 20 1995

WELL API NO.
30-015-05015

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
0G-5939

7. Lease Name or Unit Agreement Name

Robinson Unit Tr. 4 Sec.

8. Well No.
36-16

9. Pool name or Wildcat
Grayburg Jackson Q, SR, G, SA

SUNDRY NOTICES AND REPORTS CONCERNING
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator

Dwight A Tipton

3. Address of Operator

1800 North Main - Lovington, New Mexico 88260

4. Well Location

Unit Letter P : 660 Feet From The South Line and 660 Feet From The East

Section 36

Township 16-5

Range 31-E

NMPM

Eddy

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1) Spot 30 sacks of cement plug from P.B.T.D. 3890' to 3700' W.O.C. tag cement top at 3700'

2) Load Hole W/Mud

+ 3) Perforate 4 1/2 Casing 50' below base of salt at 2043' squeeze w/30 sacks of cement below packer and W.O.C. tag cement at 1943

+ 4) Perforate 4 1/2 casing 50' below 8 5/8 shoe at 375' squeeze 30 sacks of cement below packer and W.O.C. tag cement top at 275'

X 5) Perforate 4 1/2 casing at 50' circulate cement to surface between 4 1/2 and 8 3/8 casing leaving 4 1/2 full

6) Set P.A. Marker

+ spot 100' plug in side 4 1/2 no need to perforate

+ omit step 5 + place 10 sp surface plug

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Raymond J. Valverde

TITLE Supervisor

DATE 6-19-95

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

ORIGINAL SIGNED BY TIM W. GUM
DISTRICT II SUPERVISOR

APPROVED BY Mar

TITLE Supervisor

DATE JUN 23 1995

CONDITIONS OF APPROVAL, IF ANY: Mar

