

STATE OF NEW MEXICO

ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P.O. Box 2088

SANTA FE, NEW MEXICO 87501

Form C-103

Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S	
LAND OFFICE	
OPERATOR	<input checked="" type="checkbox"/>

RECEIVED BY

MAY 17 1984

O. C. D.
ARTESIA, OFFICE9a. Indicate Type of Lease
State ☒ Fee ☐

b. State Oil & Gas Lease No.

OG-1214

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT-" (FORM C-101) FOR SUCH PROPOSALS.)

XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX1. OIL WELL ☐ GAS WELL ☒ OTHER

7. Unit Agreement Name

2. Name of Operator
Read & Stevens, Inc. ☒8. Farm or Lease Name
Bogle Farms "A"3. Address of Operator
P.O. Box 1518, Roswell, NM 88201

9. Well No.

4

4. Location of Well

10. Field and Pool, or Wildcat

UNIT LETTER F 1650 FEET FROM THE North LINE AND 1650 FEET FROM
THE West LINE. SECTION 12 TOWNSHIP 16S RANGE 31E NMPM

West Mesa Upper Queen-Gas

XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX 5. Elevation (Show whether DF, RT, GR, etc.)
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX 4394.1' GL12. County
EddyXXXXXXXXXXXXXXXXXXXX
XXXXXXXXXXXXXXXXXXXX

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐PLUG AND ABANDON ☒
CHANGE PLANS ☐
☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐ALTERING CASING ☐
PLUG AND ABANDONMENT ☐
☐

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5-17-84

- 1) Set CIBP @ 3250', dump 35' of cmt.
- 2) Circulate the hole with salt gel mud.
- 3) Cut csg at \pm 2600', pull casing.
- 4) Spot 35sx, half in & half out of casing stub, 2550'-2650', wait 8hrs and tag plug.
- 5) Spot 45sx plug 2216'-2316'.
- 6) Spot 45sx plug 1250'-1350'.
- 7) Spot 45sx plug 290'-390', wait 8hrs and tag plug.
- 8) Spot 20sx plug 0'-30' w/dry hole marker 4"x10'.
- 9) Clean location and prep for inspection.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Bruce Stoltz TITLE Drilling & Production Manager DATE 5-16-84APPROVED BY Randy Brooks TITLE Geologist DATE 5-22-84

CONDITIONS OF APPROVAL, IF ANY: