

+ dsi  
dp

# OIL CONSERVATION DIVISION

P.O. Box 2088

Santa Fe, New Mexico 87501

FEB 18 1993

O.C.D.

WELL API NO. 30-015-22893
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-1111
7. Lease Name or Unit Agreement Name Lucas Store KT State Com
8. Well No. 1
9. Pool name or Wildcat Undesignated
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3592' GR

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER P&A Well <input checked="" type="checkbox"/>
2. Name of Operator YATES PETROLEUM CORPORATION
3. Address of Operator 105 South 4th St., Artesia, NM 88210
4. Well Location Unit Letter G : 1980 Feet From The North Line and 1980 Feet From The East Line Section 22 Township 17S Range 28E NMPM Eddy County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<p>NOTICE OF INTENTION TO:</p> <p>PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/></p> <p>OTHER: <input type="checkbox"/></p>	<p>SUBSEQUENT REPORT OF:</p> <p>REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/></p> <p>COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/></p> <p>CASING TEST AND CEMENT JOB <input type="checkbox"/></p> <p>OTHER: <input type="checkbox"/></p>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to P&A well. Plugging procedure reviewed by Mike Williams, NMOCD, Artesia. Set CIBP at 8550' w/35' cement on top; set CIBP at 7400' w/35' cement and set CIBP 6575' w/35' cement. Run freepoint. Shoot casing off 100' above freepoint. Pull casing and lay down. Spot 30 sx cement plug 50' in and 50' out of casing stub. Tag this plug. Spot 35 sx cement plug 5625-5525'. Spot 45 sx cement plug 3800-3700'. Spot 45 sx cement plug 2150-2050'. Tag this plug. Spot 30 sx cement plug 460-360'. Spot 10 sx cement plug 40'-Surface. Will pump FW ahead of cement and after + heavy mud. Will add CaCl2 as necessary to accelerate setting time. Cement properties: Class "C" 14.8 ppg, 6.3 gwps, 1.32 cfps. Set regulation abandonment marker. NOTIFY NMOCD, ARTESIA, NM, 24 HRS IN ADVANCE OF PLUGGING.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Juanita Goodlett TITLE Production Supervisor DATE 2-18-93

TYPE OR PRINT NAME Juanita Goodlett TELEPHONE NO. 505/748-1471

(This space for State Use)

ORIGINAL SIGNED BY  
MIKE WILLIAMS  
SUPERVISOR, DISTRICT II

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:  
Notify NMOCD in sufficient time to witness  
Plugging

FEB 23 1993