

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

RECEIVED

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.  
L 5230

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

FEB 25 '88

1. OIL WELL ☐ GAS WELL ☒ OTHER- ☐

O. C. D.  
ARTESIAN OFFICE

7. Unit Agreement Name  
South Cottonwood Draw Unit

2. Name of Operator

Jack J. Grynberg

8. Farm or Lease Name  
South Cottonwood Draw Unit

3. Address of Operator

5000 S. Quebec, Suite 500, Denver, CO 80237

9. Well No.

10. Field and Pool, or Wildcat  
Wildcat

4. Location of Well

UNIT LETTER N 1980 FEET FROM THE West LINE AND 660 FEET FROM

THE South LINE, SECTION 29 TOWNSHIP 16S RANGE 24E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)

3691' GR

12. County

Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐  
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Plug Strawn zone. Set CIBP at 6200'. Cap with 35' cement.
2. Plug Wolfcamp zone. Set CIBP at 4250'. Cap with 35' cement.
3. Circulate hole to gelled brine mud (2½ sx/10bbls.).
4. Cut off casing at approximately 4000'.
5. Set cement plug 50 feet above and below casing stub. WOC and tag to confirm.
6. Set cement plug 50 feet above and below ABO top at 3450'.
7. Set cement plug 50 feet above and below Glorieeta top at 1520'.
8. Set cement plug 50 feet above and below surface casing shoe at 930'. WOC and tag to confirm.
9. Set cement plug at surface (30').
10. Install dry hole marker. Clean up location.

NOTE: Verbal approval received from Mike Williams on February 16, 1988 at 10:00 AM.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Morris A. Sprunk  
Morris A. Sprunk

TITLE Petroleum Engineer

DATE 2/22/88

APPROVED BY Mike Williams  
Oil & Gas Inspector

TITLE \_\_\_\_\_

DATE MAR 10 1988

CONDITIONS OF APPROVAL, IF ANY: