

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Murchison Oil & Gas, Inc. ✓

3. Address and Telephone No.

1445 Ross Ave., Ste. 5300, LB 152, Dallas, Texas 75202

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Sec. 29, T17S - R27E
1980 FNL & 660 FWL

5. Lease Designation and Serial No.

USA NM 12690

6. If Indian, Allottee or Tribe Name

30-015-30768

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Potter Fed #2

9. API Well No.

Logan Draw Morrow

10. Field and Pool, or Exploratory Area

Eddy County, New Mexico

11. County or Parish, State

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to P & A this well as follows:

1. Cir 10# salt gel
 2. Set a cmt plug of 100' or 50 sx, whichever is greater, at Morrow top of 8950' & up. WOC & Tag
 3. Set a cmt plug of 100' or 50 sx, whichever is greater, at Cisco top of 7180' & up
 4. Set a cmt plug of 100' or 50 sx, whichever is greater, at Wolfcamp top of 6000' & up
 5. Set a cmt plug of 100' or 50 sx, whichever is greater, at Abo top of 4800' & up
 6. Set 100' cmt plug at 8' 5/8" csg shoe 50' above & below at 1882' and up. WOC & tag 8 5/8" J-55 32# csg set at 1832', 248 sxs cmt cir
 7. Set 100' cmt plug in 8 5/8" csg & across 13 3/8" shoe 50' above & below @ 450' & up 13 3/8" H-40 45# csg set @ 400', 84 sxs cmt cir
- Continued on attachment

14. I hereby certify that the foregoing is true and correct

Signed

[Signature]

Title Agent

Date 11-4-99

(This space for Federal or State office use)

Approved by

[Signature]

Title PETROLEUM ENGINEER

Date NOV 15 1999

Conditions of approval, if any:

