(July 1992)			- 14 M	SUBMIT IN (Other inst			
	DEPARTMEN	TED STATE	ES INTE	Tevers	TI AS OIL	OMB NO. 1004-0136 Expires: February 28, 1995	
					2	5. LEASE DEBIGNATION AND SERIAL NO.	
APP	LICATION FOR P					NM-98811 6. IF INDIAN, ALLOTTEB OR TRIBE NAME	
1a. TTPE OF WORK	_			LL ON DEEPEN	6789101		
b. TYPE WELL		DEEPEN		125	~ ° 910.	7. UNIT AGREEMENT NAME	
OIL WILL	GAS WELL OTHER	111		SINGLE			
2. NAME POPERATOR	166				m	P & PARM OR LEASE NAME WELL NO. 29812	
CONCHO RESOUT	RCES, INC. (J	IM BLOUNT)	915-		En	TO FEDERAL # 1	
			(D) [D] [Z] A	12 11	Store Cont	5/30-015-31143	
4. LOCATION OF WELL (At surface	ISIANA, SUITE 410 Report location clearly and	in accordance wi	1 EAA	State regaliements.*)	89-7443	AO. FIELD AND FOOL OF WILDCAT LOGAN DRAW - MORROW	
	60' FEL SEC. 10 7				20261	11. SEC. T. R. M. OR BUT	
At proposed prod. zo	SAME ()	, D			_	AND BUEVEY OR AREA	
14. DISTANCE IN MILES	AND DIRECTION FROM NEAR	LEST TOWN OF POS	T OFFIC	· · · · · · · · · · · · · · · · · · ·		SEC. 10 T17S-R27E	
Approximately	y 11 miles East o					12. COUNTY OF PARISH 13. STATE EDDY CO. NEW MEXICO	
15. DISTANCE FROM PROF LOCATION TO NEARES PROPERTY OR LEASE	ST					17. NO. OF ACRES ASSIGNED	
(Also to nearest dr) 18. DISTANCE FROM PRO	lg. unit line, if any)	660'		320		320	
TO NEAREST WELL, I OR APPLIED FOR, ON TH	DRILLING, COMPLETED	960 '		ROPOSED DEPTH	20. ROTAE	AY OR CABLE TOULS	
1. ELEVATIONS (Show wh	nether DF, RT, GR, etc.)		<u> </u>	9500'	 	ROTARY 22. APPROX. DATE WORK WILL START*	
3.		3425' GR.				WHEN APPROVED	
	1	PROPOSED CASE	NG ANI	CEMENTING PROGRA	м		
SIZE OF HOLE GRADE SIZE OF CASING WEIGHT PE			00 T	SETTING DEPTH	G DEPTH QUANTITY OF CEMENT		
	$\frac{\text{CONDUCTOR}}{\text{H} = 40, 12, 278 \text{H}}$	NA		40'	Cement to surface with Redi-mix		
17-2			450'		500 Sx	. circulate to surface	
124"	J-55 8 5/8"	24		1800'			
	J-55 8 5/8"	24	7	1800'	1000 S	X. 11 11 11	
7 7/8"	J-55 N-80 5 ¹ 2"	15.5 & 1		9500'	1000 S	x. Use DC tool & Circulate	
7 7/8" 1. Drill 25"	J-55 N-80 5½" hule tu 40'. Set	15.5 & 1 40' of 20	" con	9500' ductor pipe and	1000 S 1500 S cement	x. " " " " x. Use DC tool & Circulate to surface with Redi-mix.	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ ₂ " 500 Sx. of	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen	15.5 & 1 40' of 20 un and set t + 2% CaC.	" con 450' 1, ci	9500' ductor pipe and of 13 3/8" H-4 rculate cement	1000 S 1500 S cement 0 48# S to surf	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace.	
7 7/8" 1. Drill 25" 2. Drill 17½" 500 Sx. of 3. Drill 12¼"	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen	15.5 & 1 40' of 20' un and set t + 2% CaC. Run and set	" con 450' 1, ci t 180	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J-	1000 S 1500 S cement 0 48# S to surf -55 24#	x. " " " " x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ ₂ " 500 Sx. of 3. Drill 12 ¹ ₄ " 100 Sx. of 4. Drill 7 7/	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500'	15.5 & 1 40' of 20' un and set t + 2% CaC. Run and set t + additiv . Run 9500'	" con 450' 1, ci t 180 ves, ' of	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f	1000 S 1500 S cement 0 48# S to surf 55 24# t to su ollows:	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5%"	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ ₂ " 500 Sx. of 3. Drill 12 ¹ ₄ " 100 Sx. of 4. Drill 7 7/ LT&C, 6000	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' ' of 5½" J-55 15	15.5 & 1 40' of 20 un and set t + 2% CaC. Run and set t + additiv . Run 9500 .5# LT&C, 1	" con 450' 1, ci t 180 ves, ' of 1700'	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17	1000 S 1500 S cement 0 48# S to surf 55 24# t to su ollows: # LT&C	x. " " " " " " x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage	
7 7/8" 1. Drill 25" 2. Drill 17½" 500 Sx. of 3. Drill 12¼" 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' ' of 5½" J-55 15 . of Class "H" P	15.5 & 1 40' of 20 un and set t + 2% CaC Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus	" con 450' 1, ci 1, ci t 180 ves, ' of 1700' s + a	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage ce	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of	
7 7/8" 1. Drill 25" 2. Drill 17½" 500 Sx. of 3. Drill 12¼" 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' ' of 5½" J-55 15	15.5 & 1 40' of 20 un and set t + 2% CaC Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus	" con 450' 1, ci 1, ci t 180 ves, ' of 1700' s + a	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage ce	x. " " " " " " x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement lst stage ment with 600 Sx. of Notify OCD at SPUD & TIME	
7 7/8" 1. Drill 25" 2. Drill 17½" 500 Sx. of 3. Drill 12¼" 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' ' of 5½" J-55 15 . of Class "H" P	15.5 & 1 40' of 20 un and set t + 2% CaC Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus	" con 450' 1, ci 1, ci t 180 ves, ' of 1700' s + a	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage ce	<pre>x. " " " " " " " " " " " " " " " " " " "</pre>	
7 7/8" 1. Drill 25" 2. Drill 17½" 500 Sx. of 3. Drill 12¼" 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C"	J-55 N-80 $5\frac{1}{2}$ " hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of $5\frac{1}{2}$ " J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC. Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus es, circula	" com 450' 1, ci t 180 ves, ' of 1700' s + a ate c	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S cement 0 48# S to surf 55 24# t to su ollows: # LT&C tage cent e.	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of Notify OCD at SPUD & TIME to witness cementing the	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ / ₂ " 500 Sx. of 3. Drill 12 ¹ / ₄ " 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C" ABOVE SPACE DESCRIBE pen directionally, give period	J-55 N-80 $5\frac{1}{2}$ " hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of $5\frac{1}{2}$ " J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus es, circula	" com 450' 1, ci t 180 ves, ' of 1700' s + a ate c	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage cent e.	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of Notify OCD at SPUD & TIME to witness cementing the	
7 7/8" 1. Drill 25" 2. Drill 17½" 500 Sx. of 3. Drill 12¼" 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C" ABOVE SPACE DESCRIBE pen directionally, give perting	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of 5½" J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus es, circula	" com 450' 1, ci t 180 ves, ' of 1700' s + a ate c	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage cent e.	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of Notify OCD at SPUD & TIME to witness cementing the	
7 7/8" 1. Drill 25" 2. Drill 17½" 500 Sx. of 3. Drill 12¼" 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C" ABOVE SPACE DESCRIBE pen directionally, give perting	J-55 N-80 5 ¹ / ₂ " hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of 5 ¹ / ₂ " J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus es, circula	" con 450" 1, ci t 180 ves, ' of 1700' s + a ate c	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage cent e.	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of Notify OCD at SPUD & TIME to witness cementing the	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ / ₂ " 500 Sx. of 3. Drill 12 ¹ / ₄ " 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C" ABOVE SPACE DESCRIBE pen directionally, give perting	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of 5½" J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC. Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus es, circula	" con 450" 1, ci t 180 ves, ' of 1700' s + a ate c	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage cent e.	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of Notify OCD at SPUD & TIME to witness cementing the 133/% casing.	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ ₂ " 500 Sx. of 3. Drill 12 ¹ ₄ " 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C" ABOVE SPACE DESCRIBE pen directionally, give Perting SIGNED	J-55 N-80 5½" hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of 5½" J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC. Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus es, circula	" com 450' 1, ci 1 180 ves, ' of 1700' s + a ate c vetical 	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage cent e.	<pre>x. """"""""""""""""""""""""""""""""""""</pre>	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ ₂ " 500 Sx. of 3. Drill 12 ¹ ₄ " 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C" ABOVE SPACE DESCRIBE pen directionally, give pertine SIGNED (This space for Federa PERMIT NO.	J-55 N-80 5 ¹ / ₂ " hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of 5 ¹ / ₂ " J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC Run and set t + additiv . Run 9500' .5# LT&C, 1 remium Plus es, circula	" com 450' 1, ci 1, ci 180 ves, ' of 1700' s + a ate c ve data o vertical <u>A</u>	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage cer e.	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of Notify OCD at SPUD & TIME to witness cementing the 3/%	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ ₂ " 500 Sx. of 3. Drill 12 ¹ ₄ " 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C" ABOVE SPACE DESCRIBE pen directionally, give pertine SIGNED (This space for Federa PERMIT NO.	J-55 N-80 5 ¹ / ₂ " hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of 5 ¹ / ₂ " J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC Run and set t + additiv . Run 9500' .5# LT&C, 1 remium Plus es, circula	" con 450' 1, ci 1, ci 180 ves, of 1700' s + a ate c ve data o vertical A able title	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S cement 0 48# S to surf 55 24# t to su 0110ws: # LT&C tage cer e.	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of Notify OCD at SPUD & TIME to witness cementing the 3/% casing.	
7 7/8" 1. Drill 25" 2. Drill 17 ¹ ₂ " 500 Sx. of 3. Drill 12 ¹ ₄ " 100 Sx. of 4. Drill 7 7/ LT&C, 6000 with900 Sx Class "C" ABOVE SPACE DESCRIBE pen directionally, give pertine SIGNED (This space for Federa PERMIT NO. Application approval does not	J-55 N-80 5 ¹ / ₂ " hole to 40'. Set hole to 450'. R Class "C" cemen hole to 1800'. Class "C" cemen 8" hole to 9500' of 5 ¹ / ₂ " J-55 15 of Class "H" P cement + additiv	15.5 & 1 40' of 20 un and set t + 2% CaC. Run and set t + additiv . Run 9500 .5# LT&C, 1 remium Plus es, circula posal is to deepen, gived measured and rue rut.set nt holds legal or equit Acti	<pre>' com 450' 1, ci 1, ci t 180 ves, ' of 1700' s + a ate c ve data o vertical</pre>	9500' ductor pipe and of 13 3/8" H-4 rculate cement 0' of 8 5/8" J- circulate cemen 5½" casing as f of 5½" N-80 17 dditives, 2nd s ement to surfac	1000 S 1500 S 1 cement 0 48# S to surf 55 24# at to su 0110WS: # LT&C tage cer e. d proposed ne er program, if a see which would mager,	x. Use DC tool & Circulate to surface with Redi-mix. T&C casing. Cement with ace. ST&C casing. Cement with rface. 1800' of 17# N-80 5½" casing. Cement 1st stage ment with 600 Sx. of Notify OCD at SPUD & TIME to witness cementing the 	

•

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the Inited States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

SOSIVELL, NM BLM MAR I F 2000 RECEIVED

....* ₽:

Y