

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

CONTACT RECEIVED
OFFICE FOR NUMBER
OF COPIES REQUIRED
(Other instructions on reverse
side)

BLM Roswell District
Modified Form No.
NM060-3160-4

5. LEASE DESIGNATION AND SERIAL NO.
LC-028775-B

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ WIW

NM OIL CONS. COMMISSION
Drawer DD
Artesia, NM 88210

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

2. NAME OF OPERATOR

Southland Royalty Company

7. UNIT AGREEMENT NAME

Robinson Jackson Unit

3. ADDRESS OF OPERATOR

P.O. Box 51810, Midland, TX 79710-1810

3a. AREA CODE & PHONE NO.

(915)688-6800

8. FARM OR LEASE NAME

RJU Tract 2

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

1980' FSL & 660' FEL

35-17-29

JUL 9 1993

C. F. D.

10. FIELD AND POOL, OR WILDCAT

Grayburg Jackson 7R,QN

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec35, 17S, 29E

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, RT, GR, etc.)

3552' GL

12. COUNTY OR PARISH

Eddy

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐

PULL OR ALTER CASING

☐

FRACTURE TREAT

☐

MULTIPLE COMPLETE

☐

SHOOT OR ACIDIZE

☐

ABANDON*

☒

REPAIR WELL

☐

CHANGE PLANS

☐

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐

REPAIRING WELL

☐

FRACTURE TREATMENT

☐

ALTERING CASING

☐

SHOOTING OR ACIDIZING

☐

ABANDONMENT*

☐

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

MIRU Release packers. POH. RIH w/2 7/8" tubing, bit and scraper to 3125'.

RIH w/7"-20# CICR and set @ 3115'. Test tubing to 1500 psi. Cement sq. Grayburg Jackson open hole interval w/50 sxs Class C. Pull out of retainer and dump 6 sxs Class C atop same. Displace hole w/10ppg gelled brine.

RIH w/7" CIBP and set @ 2520'. Lay 25 sxs Class C CMT atop same.

RIH w/4" casing gun and perforate from 950'-951' w/4JHPF. RIH w/7" CICR and set @ 850'. Test tubing to 1000 psi. Cement w/30sxs Class C below retainer. Drop 6 sxs Class C atop same.

RIH w/4" casing gun and perforate 550'-551' w/4 JHPF.

Establish circulation down 7" casing. Displace hole w/fresh water. Mix and pump 150 sxs Class C cement and circulate to surface.

Cut off casing 3' below surface and place abandonment maker as per regulations.

Restore location as directed.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

PRODUCTION ASSISTANT

DATE

6/22/93

(This space for Federal or State office use)

APPROVED BY

(ORIG. SGD) DAVID R. GLASS

TITLE

PETROLEUM

DATE

CONDITIONS OF APPROVAL, IF ANY:

SEE ATTACHED

*See Instructions on Reverse Side