Form 3160-5 (July 1989)

UN. ED STATES DEPARTMENT OF THE INTERIOR

CONT	ACT R	ECEIV		
OFFIC	E FOR	NUMB		
OF CO	PIES R	EQUIF	LED	
(Other	instruc	ions o	rever	S @
eida)				

BLM Roswell District Modified Form No. NM060-3160-4 0/51

Formerly 9-331) DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT	(Other instructions on reverse side)	5. LEASE DESIGNATION AND SERIAL NO. LC-028775-B
SUNDRY NOTICES AND REPORTS ((Do not use this form for proposals to drill or to deepen or plug back Use "APPLICATION FOR PERMIT-" for such proposals.	to a different reservoir.	
	Artesia, NM	882 ON AGREEMENT NAME
OIL GAS OTHER WIW	Robinson Jackson Unit	
NAME OF OPERATOR	8. FARM OR LEASE NAME	
Southland Royalty Company		RJU Tract 2A
ADDRESS OF OPERATOR	3a. AREA CODE & PHONE NO.	9. WELL NO.
P.O. Box 51810, Midland, TX 79710-1810	(915)688-6800	11
. LOCATION OF WELL (Report location clearly and in accordance with any St	10. FIELD AND POOL, OR WILDCAT	
See also space 17 below.)	9 100	Grayburg Jackson 7R,Qn
At surface 660' FNL & 1980' FWL	11. SEC., T., R., M., OR BLK. AND	
DOU FAL & 1980 FWL	C. S. D.	SURVEY OR AREA Sec 35, T17S, R29E
4. PERMIT NO. 15. ELEVATIONS (Show whether	DF, RT, GR, etc.)	12. COUNTY OR PARISH 13. STATE
G. L. 3550'		Eddy NM
6. Check Appropriate Box To Indicate	te Nature of Notice. Rep	ort, or Other Data
•••	•	
NOTICE OF INTENTION TO:	50BSEC	QUENT REPORT OF:
TEST WATER SHUT-OFF PULL OR ALTER CASING	WATER SHUT-OFF	REPAIRING WELL
FRACTURE TREAT MULTIPLE COMPLETE	FRACTURE TREATMENT	ALTERING CASING
SHOOT OR ACIDIZE ABANDON*	SHOOTING OR ACIDIZING	ABANDONMENT*
REPAIR WELL CHANGE PLANS	(Other)	s of multiple completion on Well
(Other) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent	Completion or Reco	mpletion Report and Log form.)
RIH w/7" 20# CICR and set @ 2670'. Test tubing to 15 interval w/ 100 sxs Class C cement. Pull out of CIRC appg gelled brine mud. RIH w/7" CIBP and set @ 2380'. Lay 25 sxs Class C at RIH w/4" casing gun and perforate 825'-826' w/4 JS psi. Cement squeeze interval w/30 sxs Class C ceme RIH w/4" casing gun and perforate 550' 551' w/4 JHF	and dump 6 sxs Class C a top CIBP. PF. RIH w/7" CICR and set nt. Drop 6 sxs Class C at PF.	top same. Displace hole w/10 company to 1000 cop CICR.
Establish circulation down 7" casing. Displace hole $\mathbf{w}/$ and circulate same to surface.	fresh water. Mix and pun	
Cut off casing 3' below surface and place abandonme	ent marker per regulations	23 ne
		3
18. I hereby certify that the foregoing is true and correct SIGNED	Production Asst.	DATE <u>121219</u>
(This space for Federal or State office use) (ORIG. SGD) DAVID R. GLASS CONDITIONS OF APPROVAL, IF ANY:		DATE DATE

SEE ATTACHED