

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

NM OIL CONS. COMMISSION
SUBMIT IN THE CLIMATE
Drawings and Instructions on re-
vised 12/83 88610

Form approved
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		5. LEASE DESIGNATION AND SERIAL NO. NM-0467934	
2. NAME OF OPERATOR Phillips Petroleum Company ✓		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR 4001 Penbrook Street, Odessa, TX 79762		7. UNIT AGREEMENT NAME Grayburg Jackson WFU	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface Unit K, 2310' FWL & 1650' FSL		8. FARM OR LEASE NAME Tract MB	
14. PERMIT NO. 30-015-04361		9. WELL NO. Well #04	
15. ELEVATIONS (Show whether DF, RT, CR, etc.) 3623' GL		10. FIELD AND POOL, OR WILDCAT Grb. Jacks-SR-Q-Gb-SA	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 27, 17-S, 30-E	
		12. COUNTY OR PARISH Eddy	
		13. STATE NM	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	☐	WATER SHUT-OFF	☐
FRACTURE TREAT	☐	FRAC TURE TREATMENT	☐
SHOOT OR ACIDIZE	☐	SHOOTING OR ACIDIZING	☐
REPAIR WELL	☐	(Other)	☐
PULL OR ALTER CASING	☐	REPAIRING WELL	☐
MULTIPLE COMPLETE	☐	ALTERING CASING	☐
ABANDON*	☒	ABANDONMENT*	☐
CHANGE PLANS	☐		

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU DDU. NU BOP's. Clean out well to TD of 3050'. Set 7" CIBP at 3050' with tubing. Circulate 7" csg. with 9.5 ppg mud laden fluid.
2. Spot Plug No. 1 (200 sx. cmt) 2150'-3050'.
3. Perforate and squeeze with Plug No. 2 (75 sx. cmt) 1225'-1325'.
4. Free Point 7" casing. Need to pull 713'.
5. Spot Plug No. 3 (210 sx. cmt) 3'-763'.
6. RU and 1" outside of 8-5/8" surface pipe with Plug No. 4 (20 sx. cmt) 3'-50'.
7. Cut off casing 3' below G.L. Install monument marker. Perform reclamation work.

RECEIVED
MAR 17 10 51 AM '93
CALC. AREA

18. I hereby certify that the foregoing is true and correct

SIGNED <u>L. M. Sanders</u> L. M. Sanders	TITLE <u>Supv., Regulatory Affairs</u>	DATE <u>03-15-93</u> (915) 368-1488
(This space for Federal or State office use)		
APPROVED BY <u>(ORIG. SCD) DAVID R. GLASS</u>	TITLE <u>PETROLEUM ENGINEER</u>	DATE <u>APR 20 1993</u>
CONDITIONS OF APPROVAL, IF ANY:		

SEE ATTACHED

*See Instructions on Reverse Side