

Form 3160-5
November 1983)
Formerly 9-331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

NM OIL CONS. COM. STOR.
Draver SUBMIT IN TRAIL CASE
(Other instructions on re-
newals) 88210

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for each proposal.

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		5. LEASE DESIGNATION AND SERIAL NO. LC-060529	
2. NAME OF OPERATOR Phillips Petroleum Company ✓		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR 4001 Penbrook Street, Odessa, TX 79762		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface Unit L, 1650' FSL & 330' FWL		8. FARM OR LEASE NAME Beeson "F" Fed.	
14. PERMIT NO. 30-015-04398		9. WELL NO. 1	
15. ELEVATIONS (Show whether CP, RT, GR, etc.) 3560' GL		10. FIELD AND POOL, OR WILDCAT Loco Hills Q-G-SA	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 31, 17-S, 30-E	
		12. COUNTY OR PARISH Eddy	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANE

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU DDU. NU BOP's. Pull and lay down production equipment. Set 5-1/2" CIBP at 2700' with tubing. Circulate 5-1/2" casing with 9.5 mud-laden fluid.
2. Spot Plug No. 1 (120 sx.cmt) 2154-2700'.
3. Perforate and squeeze with Plug No. 2 (75 sx. cmt.) 1060-1160'.
4. Free point 7" casing. Need to pull 588'.
5. Spot Plug No. 3 (165 sx. cmt) 3'-638'.
6. RU and 1" outside of 8-5/8" surface pipe with Plug No. 4 (20 sx. cmt.) 3'-50'.
7. Cut off casing 3' below G.L. Install monument marker. Perform reclamation work.

18. I hereby certify that the foregoing is true and correct

SIGNED

L. M. Sanders
L. M. Sanders

TITLE

Supv. Regulatory Affairs

DATE

03-15-93

(915) 368-1488

(This space for Federal or State office use)

APPROVED BY

(CIVIL SERV) JOE G. LISA

TITLE

DATE

4/26/93

CONDITIONS OF APPROVAL, IF ANY:

see attached

*See Instructions on Reverse Side