

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO.
30-015-04435

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
B-4108

7. Lease Name or Unit Agreement Name:
Scheurich A

7. Well No.
#7

8. Pool name or Wildcat
Loco Hills-Q-G-SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

Yates Petroleum Corporation

3. Address of Operator

105 S. 4th Street Artesia, NM 88210

4. Well Location

Unit Letter **E** : **1650** feet from the **North** line and **330** feet from the **West** line

Section **32**

Township **17S**

Range **30E**

NMPM

Eddy

County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

3591' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>
OTHER: <input type="checkbox"/>	

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>	

Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Propose to Plug and abandon this well as follows:

Tag CIBP at 2744', above the open hole completion zone. If CIBP is absent, set a CIBP at 2734'

Spot a 30 sxs plug from CIBP to 2490' across the Queen perms 2546-2642'. -TA1

Perforate the casing at 1210' and at 525'.

Set cement retainer at 1110'. Squeeze with 45 sxs cement, leaving 35' of cement on top of retainer.

Set cement retainer at 425'. Squeeze with 60 sxs cement from 525' to near surface, leaving 35' of cement on top of retainer.

Spot a 15 sxs surface plug.

Remove all surface equipment and install dry hole marker per regulations.

**Salt gel mud consisting of 10#
Brine W/25# of gel per bbl
must be placed between each plug**

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Susan Herpin* TITLE **Engineering Technician** DATE **January 29, 2002**

Type or print name **Susan Herpin**

Telephone No. **505-748-1471**

(This space for State use)

APPROVED BY *[Signature]*

TITLE *[Signature]*

DATE **FEB 1 2002**

Conditions of approval, if any: