

8 5/8" @ 797' w/100 SX

5" @ 3456 w/100 SX TDC 3456 PB TDC 3454'

Perfs 3413-35 Bsq Lake DOD 3557'

Perfs 3374-84 meter

OH 3456-3557 - Premier

CIBP @ 3451

bed csq 1177-2512

CIBP @ 2978

TOC @ 2670'

2-9-82 2:00 PM. Jerry Schmidt called

he proposes to spot 25 SX cement on BP @ 2978

set ut @ 1850 + sq. 2-300 SX + leave @ least 50' on top of ut.
have hole @ 1911

set ret @ 11-1150 + attempt to break circ. if run dye marker
to ~~test~~ determine volume + circ. to surface.

if no circ. set BPC 750 + FC 800 + if can pump down
5 1/2" + out annulus. start pumping cement from surface.