MEMILE G. C. COPY TED STATES Form 9-331 (May 1963) Form approved. Budget Bureau No. 42-R1424. SUBMIT IN TRI ATE* DEPARTMENT OF THE INTERIOR (Other Instruction verse side) 5. LEASE DESIGNATION AND SERIAL NO. GEOLOGICAL SURVEY LC 029395 (b) 6. IF INDIAN, ALLOTTEE OR TRIBE NAME SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals.) 7. UNIT AGREEMENT NAME WELL Water Injection wel OTHER S. FARM OR LEASE NAME 2. NAME OF OPERATOR Turner "B" Atlantic Richfield Company 3. ADDRESS OF OPERATOR 9. WELL NO. DEC 1 0 1974 P. O. Box 1710, Hobbs, New Mexico 88240 LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) 10. FIELD AND POOL, OR WILDCAT o. c. c. At surface Grayburg Jackson ARTESIA, OFFICE 11. SEC., T., B., M., OR BLK. AND SURVEY OR AREA 1980' FSL & 660' FWL (Unit letter L) 17-17S-31E 14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 12. COUNTY OR PARISH | 13. STATE 3696' GR Eddy N.M. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data 16. NOTICE OF INTENTION TO: TEST WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF REPAIRING WELL FRACTURE TREAT MULTIPLE COMPLETE FRACTURE TREATMENT ALTERING CASING X SHOOTING OR ACIDIZING ABANDONMENT* SHOOT OR ACIDIZE ABANDON* REPAIR WELL CHANGE PLANS (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) (Other) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* Propose to acidize water injection well in the following manner: 1. POH w/tbg & pkr. 2. Run bit & scraper to TD 3461'. 3. Run 2-3/8" tbg & pkr to TD. Spot 200 gals acid over perforated interval 3346-3450'. 4. Set pkr @ 3310'. Acidize in seven stages w/3300 gals acid. Separate each stage w/benzoic acid flakes rock salt mix. 5. Flush w/injection water w/surfactant added. 6. Rerun tbg & pkr. Set pkr @ approx 3296' & return to water injection. RECEIVED
DEC - 9 1974 U. S. GEOLOGICAL SURVEY ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct Dist. Drlg. Supv. 12/5/74 TITLE . SIGNED DATE (This space for Federal or State office use) MAFT OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

ACTING DISTRICT ENGINEER