

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	☒
FILE	☒
U.S.G.S.	
LAND OFFICE	
OPERATOR	☒

OIL CONSERVATION DIVISION

P.O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

RECEIVED BY
JAN 9 1986

O. C. D.

5a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.
E-537-5

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER	7. Unit Agreement Name
2. Name of Operator AMOCO PRODUCTION COMPANY ☒	8. Farm or Lease Name <u>Empire South Deep Unit</u>
3. Address of Operator P. O. BOX 68 HOBBS, NEW MEXICO 88240	9. Well No. <u>11</u>
4. Location of Well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>2130</u> FEET FROM THE <u>West</u> LINE, SECTION <u>32</u> TOWNSHIP <u>17-S</u> RANGE <u>29-E</u> NMPM.	10. Field and Pool, or Wildcat <u>Empire South Wolfcamp</u>
15. Elevation (Show whether D.F., R.F., GR., etc.) <u>3609' RDB</u>	12. County <u>Eddy</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☒	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to open additional pay and stimulate as follows:
MISU and POH w/ production equipment. RIH with CIBP and set at $\pm 8200'$. Load hole w/ brine.
Run cement bond log. If top of cement is at 7600' or higher, proceed. If cement is below 7600',
perforate and squeeze to raise TCMT. Perforate Wolfcamp intervals 7698-7702', 7916-24', 7988-
8002'. RIH w/ RBP and packer. Set RBP at $\pm 8100'$ and set packer at $\pm 7850'$. Acidize perms
7916'-7924' & 7988-8002' with 2500 gals of 15% NEFEHCL. Set RBP at 7750' and packer at 7650'.
Acidize perms with 500 gals 15% NEFE acid. Pick up and POH with packer and RBP. Sand test
and evaluate production.

0+5 NMCD-H1-JRB 1-FJN 1-CMH

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles M. Serrin TITLE ADMINISTRATIVE ANALYST (SG) DATE 1/18/86
Original Signed By
APPROVED BY Les A. Clements TITLE Supervisor District 11 DATE JAN 22 1986
CONDITIONS OF APPROVAL, IF ANY: