

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPL
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 030570 B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Power Federal Comm.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Lead Cedar Lake Morrow

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

26 - 17S - 30E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3590.4 GL

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plan to Plug & Abandon this well as follows pursuant to telephone conversation with Mr. James Knauf, Artesia District Engineer with U. S. G. S. in Artesia, N. M.

1. Set Halliburton cement retainer in 8-5/8" casing @ 2800'; squeeze 300 cement below retainer into collapsed or parted casing @ 2927' & from 3239' - 3279' to shut off 1000 barrel per day waterflow from the Grayburg formation.
2. Freeport 8-5/8" casing and cut off near base of salt, pull & log down same.
3. Spot cement plug 50' in & 50' out of 8-5/8" casing stub.
4. Spot brine water gel between 8-5/8" casing stub and 13-3/8" casing stub.
5. Spot cement plug 50' in & 50' out of 13-3/8" surface casing shoe & surface casing stub.
6. Spot brine water gel between plug @ surface casing shoe and surface casing stub.
7. Spot cement plug from 20' to surface.
8. This well will be re-drilled 65' South of current location. The new re-drilled pit will be located directly over this location, therefore, the P & A marker will be set & then temporarily cut off until the new well is drilled. It will be re-erected and the location cleaned up.

18. I hereby certify that the foregoing is true and correct

Original Signed by
SIGNED Dwane W. BellTITLE Field ForemanDATE July 17, 1978

(This space for Federal or State office use)

(Orig. Sgd.) ALBERT R. STALL

ACTING DISTRICT ENGINEER

DATE JUL 19 1978

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either as shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or other plugs (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.