

NO. OF COPIES RECEIVED	17
DISTRIBUTION	
SANTA FE	1
FILE	1 v
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

MAR 29 1977

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
B - 10715

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REOPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - M (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	Artesia State Unit
Anadarko Production Company	8. Farm or Lease Name
3. Address of Operator	Tract No. 6
P. O. Box 67, Loco Hills, New Mexico 88255	9. Well No.
4. Location of Well	1
UNIT LETTER L, 2310 FEET FROM THE South LINE AND 990 FEET FROM THE West LINE, SECTION 13 TOWNSHIP 18S RANGE 27 E NMPM.	10. Field and Pool, or Wildcat
	Artesia
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3515 GR	Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pump 100 sx cement plug in open hole from TD 1927 to bottom of 7" csg. @ 1800' and into 7" csg. @ 1650'.
2. Spot 5 sx mud @ 1650'.
3. Shoot 7" csg. @ 1500'.
4. Pull 7" csg.
5. Spot 35 sx cement plug through Queen section 1550' to 1450'.
6. Spot 35 sx mud.
7. Spot 35 sx cement plug through Seven Rivers section 950' to 850'.
8. Spot 6 sx mud.
9. Spot 35 sx cement plug 50' in and 50' out of 8" casing @ 330'.
10. Spot 10 sx cement plug at surface.
11. Erect dry hole marker, close pits and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed by

SIGNED Jerry E. Buckles

TITLE Area Supervisor

DATE March 28, 1977

APPROVED BY W. A. Gussert

TITLE SUPERVISOR, DISTRICT II

DATE MAR 29 1977

Notify N.M.O.C.C. in sufficient time to witness

Plugging