

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

JUL 7 1981

O. C. D.  
ARTESIA, OFFICE

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-11540
7. Unit Agreement Name
8. Farm or Lease Name Vandevanter
9. Well No. 3
10. Field and Pool, or Wildcat Artesia
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator  
W.E. Jeffers

3. Address of Operator  
P. O. Box 65, Artesia, New Mexico 88210.

4. Location of Well  
UNIT LETTER K 1650 FEET FROM THE South LINE AND 1650 FEET FROM THE West LINE, SECTION 15 TOWNSHIP 18S RANGE 28E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPERARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Shot hole 2470' to T.D. 2500'. This well now pumping with only 785' of 8 5/8" pipe in hole. 8" open hole to 2383', 6 1/2" open hole to 2470'. Propose to fill shot hole with mud & cottonseed hulls, spot 35 sax plug at 2400' & tag. Spot 35 sax plug at Queen-1690'-1790' - 35 sax 1225' to 1325'. Determine how much 8 5/8" pipe can be pulled, spot 35 sax over shoe-735' - 835'. Pick pipe up & spot 35 sax in and over casing stub & tag. Mud between cement plugs. Cement surface plug & set marker. Clean up location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CHIEF W.E. Jeffers TITLE Owner DATE July 6-1981  
 APPROVED BY W.A. Gressett TITLE SUPERVISOR, DISTRICT II DATE JUL 8 1981

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

Pluggers