

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

MAY 9 1969

O. C. C.
ARTESIA, OFFICE

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator American Petrofina Company of Texas	8. Farm or Lease Name Humble State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 2
4. Location of Well UNIT LETTER C 330 FEET FROM THE North 1625 FEET FROM THE West 4 LINE, SECTION 18S TOWNSHIP 28E RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) 3661 DF	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 5-28-69

1. Spot 50 sk cement plug on bottom at TD 2145 through 2" KUE tubing using mud laden fluid as displacing medium.
2. Cut off 5-1/2" casing at 1302' and pull.
3. Spot 25 sk cement plug at 1302' (or 5-1/2" casing stub).
4. Spot 25 sk cement plug at 516' (bottom of 8-5/8" casing).
5. Cut off 8-5/8" casing at 158' and pull.
6. Spot 25 sk cement plug at 158' (or stub of 8-5/8" casing).
7. Place 10 sk cement plug at surface and set 4' pipe marker.

JCC/jls

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson

TITLE Asst. Dist. Mgr. of Production DATE May 8, 1969

APPROVED BY

W. A. Grossett

TITLE

OIL AND GAS INSPECTOR

DATE

MAY 12 1969

CONDITIONS OF APPROVAL, IF ANY: