

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION
JAN 8 1971

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

O. C. C.
ARTESIA, OFFICE

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. #E-7745	
7. Unit Agreement Name -	
8. Farm or Lease Name Eddy Humble State	
9. Well No. 1	
10. Field and Pool, or Wildcat Artesia	
12. County Eddy	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS	
3. Address of Operator Box 1311	
4. Location of Well UNIT LETTER <u>J</u> <u>2310</u> FEET FROM THE <u>South</u> LINE AND <u>2283.3</u> FEET FROM THE <u>East</u> LINE, SECTION <u>4</u> TOWNSHIP <u>18S</u> RANGE <u>28E</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) 3665 GR	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Start work approx. 2-15-71

Spot 25 sk. cement over producing perforations 2256-2315 through 2" EUE tubing, using mud laden fluid as displacing medium.

Cut off 7" casing @ 2100 & spot 25 sk. cement plug @ 2100

Pull casing, Spot 25 sk cement plug @ 1770 (Queen Sand)

Spot 25 sk. cement plug @ 503 (bottom of 8-5/8" casing)

Place 10 sk. cmt plug in top of 8-5/8" casing and set 4-1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson TITLE Asst. District Mgr. of Prod. DATE 1/7/71

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE JAN 8 1971
CONDITIONS OF APPROVAL, IF ANY: