

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> WIW - SX TA		7. UNIT AGREEMENT NAME WEST LOCO HILLS GRB #4 SD U	
2. NAME OF OPERATOR NEWMONT OIL COMPANY		8. FARM OR LEASE NAME TRACT 15	
3. ADDRESS OF OPERATOR P. O. BOX 1305 ARTESIA, NEW MEXICO		9. WELL NO. 2	
4. LOCATION OF WELL (Report location clearly and in accordance with any State Survey Office See also space 17 below.) At surface 330' FNL 2310' FWL Sec. 1, T18S, R29E		10. FIELD AND POOL, OR WILDCAT LOCO HILLS (O. G. SA)	
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.)	
		12. COUNTY OR PARISH EDDY	
		13. STATE NEW MEXICO	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- Spot sufficient cement across producing interval to tie back to production string casing seat, or set bridge plug near casing seat and cap with 25 sack cement plug.
- Perforate base of salt @ 1035' and squeeze with 50 sacks cement leaving 100' plug in casing.
- Perforate top of salt @ 500' and squeeze with 50 sacks cement leaving 100' plug in casing.
- Set 15 sack cement plug @ surface tying surface and production casing together.
- Erect permanent well marker

Note: (a). Your office will be notified 24 hrs. prior to operations
(b.) All plugs will be verified
(c.) Hole will be loaded between all plugs with 10# Mud
(d) We do not plan to pull any casing

18. I hereby certify that the foregoing is true and correct

SIGNED Peter W. Chester TITLE Area Manager DATE 7/23/82

(This space for Federal or State Office Use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

AUG 4 1982

FOR JAMES A. GILLHAM *See Instructions on Reverse Side
DISTRICT SUPERVISOR