

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN DUPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		2. NAME OF OPERATOR Atlantic Richfield Company		3. ADDRESS OF OPERATOR P. O. Box 1978, Roswell, New Mexico 88401		4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1650' FNL & 660' FWL (Unit letter E)		5. LEASE DESIGNATION AND SERIAL NO. LC 029395 (b)		6. IF INDIAN, ALLOTTEE OR TRIBE NAME		7. UNIT AGREEMENT NAME		8. FARM OR LEASE NAME Turner "B"		9. WELL NO. 58		10. FIELD AND POOL, OR WILDCAT Undesignated		11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA Sec. 29, T17S, R31E		12. COUNTY OR PARISH Eddy		13. STATE N.M.	
14. PERMIT NO.				15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3644' GR																					

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was drilled in 1959 and was not commercial in the deeper zones. On 1/7/60 a 10 sack cement plug from 9845-9757 was set and the 5½" casing was filled with heavy mud. We propose to P & A the well as follows: Note: The wellbore is not needed in Grayburg Jackson waterflood operations.

1. Shoot off and pull 5½" csg from free point (top of cmt @ 9430').

2. Set these cement plugs leaving 9#/gal gel mud between them:

35 sx @ 5½" stub

35 sx across top of Wolfcamp @ 8400' if 5½" stub below this depth.

35 sx across top of Tubb @ 6552' if 5½" stub below this depth.

35 sx across top of Glorieta @ 5020' if 5½" stub below this depth.

35 sx in & out of 9-5/8" shoe @ 3825'.

10 sx in top of well.

Erect dry hole marker. Clear and level location. 13-3/8" and 9-5/8" casing to remain intact.

18. I hereby certify that the foregoing is true and correct

SIGNED

C.D. Dutches

TITLE

Dist. Drlg. Supervisor

DATE

9/27/71

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

SEP 29 1971

R. L. BEEKMAN

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

SEP 30 1971

O.C.C.

ARTESIA, OFFICE