

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1 ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

MAR 1 1973

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-7868	
7. Unit Agreement Name	
Hope Unit	
8. Farm or Lease Name	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
South Hope-Penn Gas	
12. County	
Eddy	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐

2. Name of Operator
SUN OIL COMPANY ✓

3. Address of Operator
P. O. BOX 1861, MIDLAND, TEXAS 79701

4. Location of Well
UNIT LETTER **J**, **1980** FEET FROM THE **South** LINE AND **1980** FEET FROM
THE **East** LINE, SECTION **19** TOWNSHIP **18-S** RANGE **23-E** NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
GR 4071

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU - Load hole w/9.5# mud, unseat Mod-R-Pkr & circ. Run tbg to 7100'. *FS 7155-88*
 2. Spot cmt @ tbg point. Set dwn to Mod-D-Pkr & Squeeze w/25 sxs. cmt.
 3. Spot 25 sxs. above & below Mod-D.
 4. Spot 30 sxs plug 5800-6100' & POOH.
 5. Locate free point, cut 5½" csg. & pull. *TOE C5425 by Temporary*
 6. Run tbg. & spot 100' plug (21 sxs.) 50' inside 5½" & 50' in OH.
 7. Spot 30 sxs. 3400-3500', 30 sxs 1750-1850' & 30 sxs. 550-650'. POOH.
 8. Place 10' cmt. plug @ surface, cut csg & weld steel plate w/marker.
 9. Clean location - P&A Final
- FS 5870-6040*

Note: Anticipated plugging date - 5-1-73.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>Charles Gray</i>	TITLE Proration Clerk	DATE 2-28-73
APPROVED BY <i>W. A. Gressett</i>	TITLE OIL AND GAS INSPECTOR	DATE MAR 2 1973
CONDITIONS OF APPROVAL, IF ANY: Notify N.M.O.C.C. in sufficient time to witness <i>Plus...</i>		