

Submit 3 copies
to Appropriate
District Office

Form C-103
Revised 11-89

CLSF op

State of New Mexico
Energy, Minerals and Natural Resources Department

DISTRICT I

P.O. Box 1980, Hobbs NM 88240

DISTRICT II

P.O. Drawer DD, Artesia NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-015-20676

5. Indicate Type of Lease

State ☒ FEE

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name

WLHU TRACT 29

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL GAS
WELL WELL OTHER INJECTION

2. Name of Operator

Yates Petroleum Corporation

3. Address of Operator

105 South 4th., Artesia, NM 88210

8. Well No.

3

9. Pool Name or Wildcat

OGO HILLS QUEEN GRAYBURG, SAN ANDRE

4. Well Location

Unit Letter N : 990 Feet From The SOUTH Line and 2245 Feet From The WEST Line

Section 2 Township 18S Rang. 29E NMPM EDDY COUNTY

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK

PLUG AND ABANDON

☒

TEMPORARILY ABANDON

CHANGE PLANS

☐

PULL OR ALTER CASING

☐

OTHER

☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK

☐

ALTERING CASING

☐

COMMENCE DRILLING OPNS.

☐

PLUG AND ABANDONMENT

☐

CASING TEST AND CEMENT JOB

☐

OTHER

☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

YATES PETROLEUM CORPORATION PROPOSES TO TEMPORARILY ABANDON AS FOLLOWS:

1. MIRU PU & safety equipment. No casing recovery will be attempted. TOH w/ tubing.
2. TIH w/ tubing; load hole w/ plugging mud. Spot 20 sk Class C cement plug from 2576'-2695' across Grayburg perms. Circ clean & POH. WOC & tag plug; reset if necessary.
3. TIH w/ tubing; load hole w/ plugging mud. Spot 20 sk Class C cement plug from 925'-1025' across base of salt. Circ clean & POH. WOC & tag plug; reset if necessary.
4. TIH w/ tubing; load hole w/ plugging mud. Spot 20 sk Class C cement plug from 290'-390' across surface casing shoe & top of salt. Circ clean & POH. WOC & tag plug; reset if necessary.
5. Spot 15 sk Class C cement plug @ surface. — *Perf Both strings of cs? @ 40' place cnt. inside? outside of Both strings 0-40'*
6. Remove all surface equipment & weld dry hole marker per regulations.

I hereby certify that the information above is a true and complete to the best of my knowledge and belief.

SIGNATURE

Donna Clack
DONNA CLACK

TITLE

Regulatory Technician

DATE

6/19/02

TELEPHONE NO

505-748-1471

TYPE OR PRINT NAME

(This space for State Use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

Wild Sep ID

DATE

JUN 19 2002