

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions
reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.
LC-058580

6. IF INDIAN, ALLOTTEE OR TRIBE NAME
0

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Empire South Deep Unit

9. WELL NO.

14

10. FIELD AND POOL, OR WILDCAT
South-Empire Wolfcamp

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

5-18-29

12. COUNTY OR PARISH

Eddy

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Amoco Production Company

3. ADDRESS OF OPERATOR

P. O. Box 68 Hobbs, NM 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1650' FNL x 2010' FEL
(Unit G, SW/4, SW/4)

RECEIVED BY

NOV 24 1986

O. C. D.
ARTESIA, OFFICE

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3563.5 GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to permanently plug and abandon subject well.

MIRU - SU. POH w/production equip. RIH w/CIBP and set at 7900'. Cap w/35' class C neat cement. RIH w/tubing and circulate 5-1/2" casing w/200 bbls of 10# brine w/25# gel/bbl. Pull up and spot a 50 sack class c neat cement plug in the 5-1/2" casing from 5200'-5600'. Pull up and spot a 50 sack class c neat cement plug in the 5-1/2" casing from 2700'-3100'. RIH w/3-1/8" casing gun and perf 450'-451' w/4 SPF. Pump down 5-1/2" casing and establish circulation w/9-5/8" - 5-1/2" annulus. Pump down 5-1/2" casing w/200 sack class c neat cement. Circulate cement to surface through 9-5/8" - 5-1/2" annulus. Shut-in 5-1/2" casing. Dig out cellar and cut off wellhead. Cap well and erect abandonment marker.

18. I hereby certify that the foregoing is true and correct

SIGNED Steve Brownlee

TITLE Admin. Analyst

DATE 11-13-86

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE 11-19-86

*See Instructions on Reverse Side

